



VS150 / VS2
SERVICE MANUAL



This service manual contains the technical data of each component inspection and repair for the VS150 / VS2 motorcycle. The manual is shown with illustrations and focused on “Service Procedures”, “Operation Key Points”, and “Inspection Adjustment” so that provides technician with service guidelines.

If the style and construction of the motorcycle, VS150 / VS2, are different from that of the photos, pictures shown in this manual, the actual vehicle shall prevail. Specifications are subject to change without notice.

Service Department
VMEP COMPANY

Page	Content	Index
3-1 ~ 3-18	GENERAL INFORMATION	3
4-1 ~ 4-13	SERVICE MAINTENANCE INFORMATION	4
5-1 ~ 5-8	LUBRICATION SYSTEM	5
6-1 ~ 6-12	FUEL SYSTEM	6
7-1 ~ 7-8	ENGINE REMOVAL	7
8-1 ~ 8-14	CYLINDER HEAD/VALVE	8
9-1 ~ 9-8	CYLINDER/PISTON	9
10-1 ~ 10-14	“V” TYPE BELT DRIVING SYSTEM/KICK-STARTER	10
11-1 ~ 11-10	FINAL DRIVING MECHANISM	11
12-1 ~ 12-8	ALTERNATOR	12
13-1 ~ 13-9	CRANKSHAFT/ CRANKCASE	13
14-1 ~ 14-16	BODY COVER	14
15-1 ~ 15-14	BRAKE SYSTEM	15
16-1 ~ 16-11	STEERING/FRONT WHEEL/SUSPENSION	16
17-1 ~ 17-6	REAR WHEEL/SUSPENSION	17
18-1 ~ 18-18	ELECTRICAL EQUIPMENT	18
19-1 ~ 19-2	ELECTRICAL DIAGRAM	19

VS150/VS2



This service manual describes basic information of different system parts and system inspection & service VS150 / VS2 motorcycles. In addition, please refer to the manual contents in detailed for the model you serviced in inspection and adjustment.

The first chapter covers general information and trouble diagnosis.

The second chapter covers service maintenance information and special tools manual.


The third to the 11th chapters cover engine and driving systems.

The 12th to the 17th chapter is contained the parts set of assembly frame body and body cover.

The 18th chapter is electrical equipment.

The 19th chapter is wiring diagram.

Please see index of content for quick having the special parts and system information.



Symbols and Marks..... 3-1	Specifications..... 3-10
General safety..... 3-2	Torque Values 3-11
Service Precautions 3-3	Troubles Diagnosis 3-13
Specifications..... 3-9	Parts to Be Greased 3-17

Symbols and Marks

Symbols and marks are used in this manual to indicate what and where the special service are needed, in case supplemental information is procedures needed for these symbols and marks, explanations will be added to the text instead of using the symbols or marks.

	Warning	Means that serious injury or even death may result if procedures are not followed.
	Caution	Means that equipment damages may result if procedures are not followed.
	Engine oil	Limits to use SHARK 4T (SAE 20W-50 API SG) class oil. Warranty will not cover the damage that caused by not apply with the limited engine oil. (Recommended oil: SHARK 4T oil)
	Grease	SHARK 4T is recommended.
	Gear oil	SHARK gear oil serials are recommended. (SUPER HYPOID GEAR OIL # 150)
	Locking sealant	Apply sealant, medium strength sealant should be used unless otherwise specified.
	Oil seal	Apply with lubricant. °
	Renew	Replace with a new part before installation.
	Brake fluid	Use recommended brake fluid DOT3 or WELLRUN brake fluid.
	Special tools	Special tools
	Correct	Meaning correct installation.
	Wrong	Meaning wrong installation.
	Indication	Indication of components.
	Directions	Indicates position and operation directions
		Components assembly directions each other.
		Indicates where the bolt installation direction, --- means that bolt cross through the component (invisibility).

General safety

Carbon monoxide

If you must run your engine, ensure the place is well ventilated. Never run your engine in a closed area. Run your engine in an open area, if you have to run your engine in a closed area, be sure to use an extractor.

Caution

Exhaust contains toxic gas which may cause one to lose consciousness and even result in death.

Gasoline

Gasoline is a low ignition point and explosive material. Work in a well-ventilated place, no flame or spark should be allowed in the work place or where gasoline is being stored.

Caution

Gasoline is highly flammable, and may explode under some conditions, keep it away from children.

Used engine oil

Caution

Prolonged contact with used engine oil (or transmission oil) may cause skin cancer although it might not be verified.

We recommend that you wash your hands with soap and water right after contacting. Keep the used oil beyond reach of children.

Hot components

Caution

Components of the engine and exhaust system can become extremely hot after engine running. They remain very hot even after the engine has been stopped for some time. When performing service work on these parts, wear insulated gloves and wait until cooling off.

Battery

Caution

- Battery emits explosive gases; flame is strictly prohibited. Keep the place well ventilated when charging the battery.
- Battery contains sulfuric acid (electrolyte) which can cause serious burns so be careful do not be spray on your eyes or skin. If you get battery acid on your skin, flush it off immediately with water. If you get battery acid in your eyes, flush it off immediately with water and then go to hospital to see an ophthalmologist.
- If you swallow it by mistake, drink a lot of water or milk, and take some laxative such as castor oil or vegetable oil and then go to see a doctor.
- Keep electrolyte beyond reach of children.

Brake shoe

Do not use an air hose or a dry brush to clean components of the brake system, use a vacuum cleaner or the equivalent to avoid dust flying.

Caution

Inhaling brake shoe or pad ash may cause disorders and cancer of the breathing system


Brake fluid

Caution


Spilling brake fluid on painted, plastic, or rubber parts may cause damage to the parts. Place a clean towel on the above-mentioned parts for protection when servicing the brake system. Keep the brake fluid beyond reach of children.

Service Precautions


- Always use with VMEP genuine parts and recommended oils. Using non-designed parts for VMEP motorcycle may damage the motorcycle.




- Special tools are designed for remove and install of components without damaging the parts being worked on. Using wrong tools may result in parts damaged.




- When servicing this motorcycle, use only metric tools. Metric bolts, nuts, and screws are not interchangeable with the English system, using wrong tools and fasteners may damage this vehicle.
- Clean the outside of the parts or the cover before removing it from the motorcycle. Otherwise, dirt and deposit accumulated on the part's surface may fall into the engine, chassis, or brake system to cause a damage.
- Wash and clean parts with high ignition point solvent, and blow dry with compressed air. Pay special attention to O-rings or oil seals because most cleaning agents have an adverse effect on them.




- Never bend or twist a control cable to prevent unsmooth control and premature worn out.



- Rubber parts may become deteriorated when old, and prone to be damaged by solvent and oil. Check these parts before installation to make sure that they are in good condition, replace if necessary.
- When loosening a component which has different sized fasteners, operate with a diagonal pattern and work from inside out. Loosen the small fasteners first. If the bigger ones are loosen first, small fasteners may receive too much stress.
- Store complex components such as transmission parts in the proper assemble order and tie them together with a wire for ease of installation later.




- Note the reassemble position of the important components before disassembling them to ensure they will be reassembled in correct dimensions (depth, distance or position).
- Components not to be reused should be replaced when disassembled including gaskets metal seal rings, O-rings, oil seals, snap rings, and split pins.




3. GENERAL INFORMATION




- The length of bolts and screws for assemblies, cover plates or boxes is different from one another, be sure they are correctly installed. In case of confusion, Insert the bolt into the hole to compare its length with other bolts, if its length out side the hole is the same with other bolts, it is a correct bolt. Bolts for the same assembly should have the same length.




- Tighten assemblies with different dimension fasteners as follows: Tighten all the fasteners with fingers, then tighten the big ones with special tool first diagonally from inside toward outside, important components should be tightened 2 to 3 times with appropriate increments to avoid warp unless otherwise indicated. Bolts and fasteners should be kept clean and dry. Do not apply oil to the threads.




- When oil seal is installed, fill the groove with grease, install the oil seal with the name of the manufacturer facing outside, check the shaft on which the oil seal is to be installed for smoothness and for burrs that may damage the oil seal.




- Remove residues of the old gasket or sealant before reinstallation, grind with a grindstone if the contact surface has any damage.




- The ends of rubber hoses (for fuel, vacuum, or coolant) should be pushed as far as they can go to their connections so that there is enough room below the enlarged ends for tightening the clamps.



- Rubber and plastic boots should be properly reinstalled to the original correct positions as designed.




- The tool should be pressed against two (inner and outer) bearing races when removing a ball bearing. Damage may result if the tool is pressed against only one race (either inner race or outer race). In this case, the bearing should be replaced. To avoid damaging the bearing, use equal force on both races.



Both of these examples can result in bearing damage.


- Lubricate the rotation face with specified lubricant on the lubrication points before assembling.




- Check if positions and operation for installed parts is in correct and properly.




- Make sure service safety each other when conducting by two persons.




- Note that do not let parts fall down.




- Before battery removal operation, it has to remove the battery negative (-) cable firstly. Notre tools like open-end wrench do not contact with body to prevent from circuit short and create spark.




- After service completed, make sure all connection points is secured. Battery positive (+) cable should be connected firstly.
- And the two posts of battery have to be greased after connected the cables.



- Make sure that the battery post caps are located in properly after the battery posts had been serviced.




- If fuse burned, it has to find out the cause and solved it. And then replace with specified capacity fuse.



3. GENERAL INFORMATION


- When separating a connector, it locker has to be unlocked firstly. Then, conduct the service operation.




- Do not pull the wires as removing a connector or wires. Hold the connector body.




- Make sure if the connector pins are bent, extruded or loosen.




- Insert the connector completely.
If there are two lockers on two connector sides, make sure the lockers are locked in properly.
Check if any wire loose.




- Check if the connector is covered by the twin connector boot completely and secured properly.




- Before terminal connection, check if the boot is crack or the terminal is loose.




- Insert the terminal completely.
Check if the terminal is covered by the boot.
Do not let boot open facing up.



- Secure wires and wire harnesses to the frame with respective wire bands at the designated locations. Tighten the bands so that only the insulated surfaces contact the wires or wire harnesses.




- Wire band and wire harness have to be clamped secured properly.




- Do not squeeze wires against the weld or its clamp.




- Do not let the wire harness contact with rotating, moving or vibrating components as routing the harness.




- Keep wire harnesses far away from the hot parts.




- Route wire harnesses to avoid sharp edges or corners and also avoid the projected ends of bolts and screws.




- Route harnesses so that they neither pull too tight nor have excessive slack.




- Protect wires or wire harnesses with electrical tape or tube if they contact a sharp edge or corner. Thoroughly clean the surface where tape is to be applied.




- Secure the rubber boot firmly as applying it on wire harness.



- Never use wires or harnesses which insulation has been broken. Wrap electrical tape around the damaged parts or replace them.




- Never clamp or squeeze the wire harness as installing other components.




3. GENERAL INFORMATION


- Do not let the wire harness been twisted as installation.




- Wire harnesses routed along the handlebar should not be pulled too tight or have excessive slack, be rubbed against or interfere with adjacent or surrounding parts in all steering positions.



- Before operating a test instrument, operator should read the operation manual of the instrument. And then, conduct test in accordance with the instruction.



- With sand paper to clean rust on connector pins/terminals if found. And then conduct connection operation later.



Specifications

MAKER			VMEP		MODEL		HA15A6-4 (VS2)		
Dimension	Overall Length		1910 mm		Suspension System		Front	Telescopic Fork	
	Overall Width		740 mm				Rear	Twin Unit Swing	
	Overall Height		1125 mm		Tire Specifications		Front	110 / 80 – 12 61L	
	Wheel Base		1345 mm				Rear	130 / 70 – 12 64L	
Weight	Curb Weight	Front	58 kg		Brake System		Front	Disk (ϕ 273 mm)	
		Rear	75 kg				Rear	Drum (ϕ 130 mm)	
		Total	133 kg						
	Passengers/Weight		Two /110 kg		Performance	Max. Speed	Above 100 km/h		
	Total Weight	Front	88 kg			Climb Ability	Below 28°		
		Rear	155 kg		Reduction	Primary Reduction	Belt, 2.56 ~ 0.8		
		Total	243 kg			Secondary Reduction	Gear		
	Type		4-Stroke Engine				Clutch	Centrifugal, dry type	
Installation and arrangement		Vertical, below center, incline 80°		Transmission	C.V.T				
Fuel Used		Unlead gasoline		Speedometer			0 ~ 140 km/h		
Engine	Cycle/Cooling		4-stroke/water cooled		Horn		93~112 dB/A		
	Cylinder	Bore	57.4 mm		Muffler		Expansion & Pulse Type		
		Stroke	57.8 mm		Exhaust Pipe Position and Direction		Right side, and Backward		
		Number/Arrangement		Single Cylinder		Lubrication System		Forced circulation & splashing	
	Displacement		149.6 cm ³		Exhaust Concentration	Solid Particulate			
	Compression Ratio		11.2 : 1			CO		Below 5.5 g/ km	
	Max. HP		9 Kw / 8000 r.p.m			HC		Below 1.2 g/ km	
	Max. Torque		12.16 Nm / 6500 r.p.m		E.E.C.		—		
	Ignition system		C.D.I. electronic ignition		P.C.V.		—		
	Starting System		Kick and electrical starter		Catalytic reaction control system		Yes		

3. GENERAL INFORMATION



Specifications

MAKER			VMEP		MODEL		VS3		
Dimension	Overall Length		1910 mm		Suspension System		Front	Telescopic Fork	
	Overall Width		740 mm				Rear	Twin Unit Swing	
	Overall Height		1125 mm		Tire Specifications		Front	110 / 80 -12 61L	
	Wheel Base		1345 mm				Rear	130 / 70 -12 64L	
Weight	Curb Weight	Front	58 kg		Brake System		Front	Disk (ϕ 273 mm)	
		Rear	75 kg				Rear	Drum (ϕ 130 mm)	
		Total	133 kg						
	Passengers/ Weight		Two/110 kg		Performance	Max. Speed	Above 100 km/h		
	Total Weight	Front	88 kg			Climb Ability	Below 28°		
		Rear	155 kg		Reduction	Primary Reduction	Belt		
		Total	243 kg	Secondary Reduction		Gear			
	Clutch			Centrifugal, dry type					
Engine	Type		4-Stroke Engine			Transmission	C.V.T.		
	Installation and arrangement		Vertical, below center, incline 80°						
	Fuel Used		Unlead gasoline			Speedometer		0 ~ 140 km/h	
	Cycle/Cooling		4-Stroke/Water Cooled		Horn		93~112 dB/A		
	Cylinder	Bore	52.4 mm		Muffler		Expansion & Pulse Type		
		Stroke	57.8 mm		Exhaust Pipe Position and Direction		Right side, and Backward		
		Number / Arrangement	Single Cylinder		Lubrication System		Forced circulation & splashing		
	Displacement		124.6 cm ³		Exhaust Concentration	Solid Particulate			
	Compression Ratio		11.2 : 1			CO		Below 5.5 g/km	
	Max. HP		11.1PS / 8000 rpm			HC		Below 1.2 g/km	
	Max. Torque		10.12Nm / 6500 rpm		E.E.C.		—		
	Ignition		C.D.I.		P.C.V.		—		
	Starting System		Power & Foot		Catalytic Reaction Control System		Yes		

Torque Values

The torque values listed in above table are for more important tighten torque values. Please see standard values for not listed in the table.

Standard Torque Values for Reference

Type	Tighten Torque	Type	Tighten Torque
5 mm bolt 、nut	0.45~0.6kgf-m	5 mm screw	0.35~0.5kgf-m
6 mm bolt 、nut	0.8~1.2kgf-m	6 mm screw 、SH nut	0.7~ 1.1kgf-m
8 mm bolt 、nut	1.8~2.5kgf-m	6 mm bolt 、nut	1.0 ~1.4kgf-m
10 mm bolt 、nut	3.0~4.0kgf-m	8 mm bolt 、nut	2.4 ~3.0kgf-m
12 mm bolt 、nut	5.0~6.0kgf-m	10 mm bolt 、nut	3.5~4.5kgf-m

Engine Torque Values

Item	Q'ty	Thread Dia. (mm)	Torque Value(kgf-m)	Remarks
Cylinder head nut	4	8	2.0~2.4	Apply oil to thread
Cylinder head right bolt	2	8	2.0~2.4	
Cylinder head stud bolt (inlet pipe)	2	6	0.7~1.1	
Cylinder head stud bolt (EX. pipe)	2	7	0.5~1.0	
Tappet adjustment hole cap bolt	6	6	1.0~1.4	
Tappet adjustment screw nut	4	5	0.7~1.1	
Spark plug	1	10	1.0~1.2	
Carburetor insulator bolt	2	6	0.7~1.1	
Cylinder stud bolt	4	8	0.7~1.1	
Engine left cover bolt	7	6	1.1~1.5	
Engine oil draining bolt	1	12	1.1~1.5	
Engine oil strainer cap	1	30	1.3~1.7	
Mission draining bolt	1	8	0.8~1.2	
Mission filling bolt	1	10	0.8~1.2	
Clutch driving plate nut	1	28	5.0~6.0	
Clutch outer nut	1	12	5.0~6.0	
Drive face nut	1	12	5.0~6.0	
Flywheel nut	1	12	5.0~6.0	
Crankcase bolts	7	6	0.8~1.2	
Mission case bolt	7	8	2.0~2.4	

3. GENERAL INFORMATION




Frame Torque Values


Item	Q'ty	Thread Dia. (mm)	Torque Value(kgf-m)	Remarks
Stopper nut for engine hanger rubber	1	8	1.8~2.2	
Engine hanger nut	2	12	4.0~5.0	
Engine hanger bolt	1	12	4.0~5.0	
Engine connection bolt	1	10	3.5~4.5	
Front wheel axle nut	1	12	5.0~7.0	
Rear wheel shaft nut	1	14	10.0~12.0	
Rear fork	2	8	4.0~5.0	
Rear cushion upper bolt	2	10	3.5~4.5	
Rear cushion under bolt	2	8	2.4~3.0	
Nut for steering post	1	10	4.0~5.0	
Front cushion	4	8	2.4~3.0	
Brake lever nut	2	6	0.8~1.2	
Nut for the rear brake arm	1	6	0.5~0.6	
Front brake hose bolt	4	10	3.0~4.0	
Front brake caliper bolt	4	6	3.0~3.5	
Front brake disk mounting bolt	7	8	4.0~4.5	
Air-bleed valve	1	5	0.5~0.6	
Speedometer cable locking screw	1	5	0.15~0.3	
Exhaust muffler bolt	3	8	3.2~3.8	
Exhaust muffler connection nut	2	7	1.0~1.2	

Troubles Diagnosis


A. Engine hard to start or can not be started




B. Engine run sluggish (Speed does not pick up, lack of power)




C. Engine runs sluggish (especially in low speed and idling)




D. Engine runs sluggish (High speed)



E. Clutch, driving and driving pulley



Parts to Be Greased



Notes:

Precautions in Operation	4-1	Brake Light Switch/Starting Inhibitor Switch	4-10
Periodical Maintenance Schedule	4-2	Headlight Beam Distance	4-10
Fuel Lines / Cable	4-3	Clutch Disc Wear	4-10
Air Cleaner	4-4	Side Stand	4-11
Spark Plug	4-4	Cushion	4-11
Valve Clearance	4-5	Nuts, Bolts Tightness	4-11
Carburetor Idle Speed Adjustment	4-6	Wheel/Tire	4-12
Ignition System	4-7	Steering Handle Top Bearing	4-12
Cylinder Compression Pressure	4-7		
Drive Belt	4-8		
Brake System (Front Disk Brake)	4-8		

Precautions in Operation

4

Specification

Fuel Tank Capacity		6000 c.c.
Engine Oil	Capacity	1000 c.c.
	Change	900 c.c.
Transmission Gear oil	Capacity	150 c.c.
	Change	120 c.c.
Clearance of throttle valve		2~6 mm
Spark plug	Type	NGK CR8E
	Gap	0.6~0.7 mm
“F” Mark in idling speed		BTDC 13° / 1700 rpm
Full timing advanced		BTDC 28° / 4000 rpm
Idling speed		1600±100 rpm
Cylinder compression pressure		12.0 ±0.2 kgf/cm ²
Valve clearance: IN/EX		0.12 ± 0.02 mm
Tire dimension	Front	110/80-12 61L
	Rear	130/70-12 64L
Tire pressure (cold)	Single	Front: 1.75 kg/cm ² rear : 2.25 kg/cm ²
	Two persons	Front: 1.75 kg/cm ² rear : 2.50 kg/cm ²
Battery		12V8Ah (MF battery) type: TTZ10S

4. MAINTENANCE INFORMATION



Periodical Maintenance Schedule

Maintenance Code	Item	Every 300KM	1 Month every 1,000KM	3 month every 3,000KM	6 month every 6000KM	1 year every 12,000KM	15 month every 14,500KM
1	☆Air cleaner	I		C		R	
2	☆2nd air jet leaner	I		C		R	
3	☆Fuel filter	I			I	R	
4	☆Oil filter	C			C		
5	☆Engine oil change	R	Replacement for every 1000 km				
6	Tire pressure	I	I				
7	Battery inspection	I	I				
8	Brake & free ply check	I	I				
9	Steering handle check	I			I		
10	Cushion operation check	I			I		
11	Every screw tightening check	I	I				
12	Gear oil check for leaking	I	I				
13	☆Spark plug check or change	I		I	R		
14	☆Gear oil change	R	Replacement for every 5000 km				
15	Frame lubrication				L		
16	Exhaust pipe	I	I				
17	☆Ignition timing	I	I				
18	☆emission check in Idling	A	I				
19	☆Throttle operation	I		I			
20	☆Engine bolt tightening	I		I			
21	☆CVT driving device(belt)				I	R	
22	☆CVT driving device(roller)				C		
23	Lights/electrical equipment/multi-meters	I	I				
24	Main/side stands & springs	I			I		
25	Fuel lines	I		I			
26	Cushions			I			
27	Cam chain	I		I			
28	☆Valve clearance	I		A			
29	☆Crankcase evaporative control system	I		C			
30	☆Crankcase blow-by over-flow		Replacement for every 2000 km				
31	☆2nd air jet system	I		I	C		

Code: I ~ Inspection, cleaning, and adjustment R ~ Replacement C ~ Cleaning (replaced if necessary) L ~ Lubrication
Have your motorcycle checked, adjusted, and recorded maintenance data periodically by your SYM Authorized Dealer to maintain the motorcycle at the optimum condition

The above maintenance schedule is established by taking the monthly 1000 kilometers as a reference which ever comes first.


- Remarks: 1. There marks "☆" in the schedule are emission control items. According to EPA regulations, these items must be performed normally periodical maintenance following the use r manual instructions. They are prohibited to be adjusted or repaired by unauthorized people. Otherwise, SYM is no responsible for the charge.
2. Clean or replace the air cleaner element more often when the motorcycle is operated on dusty roads or in the Heavily- polluted environment.
3. Maintenance should be performed more often if the motorcycle is frequently operated in high speed and after the motorcycle has accumulated a higher mileage.
4. Preventive maintenance
- Ignition system — Perform maintenance and check when continuous abnormal ignition, misfire, after-burn, overheating occur.
 - Carbon deposit removal — Remove carbon deposits in cylinder head, piston heads, exhaust system when power is obvious lower. Than ever

Fuel Lines / Cable

Remove luggage box.
Remove rear carrier.
Remove body covers.
Check all lines, and replace it when they are deterioration, damage or leaking.

Warning

Gasoline is a low ignition material so any kind of fire is strictly prohibited as dealing it.



Acceleration Operation

Have a wide open of throttle valve as handle in any position and release it to let back original (full closed) position.
Check handle if its operation is smooth.
Check acceleration cable and replace it if deteriorated, twisted or damaged.
Lubricate the cable if operation is not smooth.
Measure the throttle grip free play in its flange part.



Adjustment can be done in either end.
Secondary adjustment is conducted from top side.
Remove rubber boot, loosen fixing nut, and then adjust it by turning the adjustment nut.

Primary adjustment is conducted from bottom side.

Loosen fixing nut, and adjust by turning the adjustment nut.

Tighten the fixing nut, and check acceleration operation condition.

Free play: 2~6 mm.



Air Cleaner


Air Cleaner Element

Remove 6 screws from the air cleaner cover and then remove the cover.

Remove 6 screws, and then remove the air cleaner element.


Caution

The air cleaner element is made of paper so do not soap it into water or wash it with water.



Spark Plug

Remove central cover.
Remove spark plug cap.
Clean dirt around the spark plug hole.
Remove spark plug.




Measure the spark plug gap.
Spark plug gap : $0.6 \div 0.7$ mm
Carefully bend ground electrode of the plug to adjust the gap if necessary.
Hold spark plug washer and install the spark plug by screwing it.

Tighten torque: 1.0~1.2kgf-m

Connect spark plug cap.

Recommended spark plug: NGR CR8E



Valve Clearance

Caution

Checks and adjustment must be performed when the engine temperature is below 35°C.

Remove trunk.

Remove central cover.

Remove valve adjustment cap.

Remove cylinder head side cover.

Turn camshaft bolt in C.W. direction and let the "T" mark on the camshaft sprocket align with cylinder head mark so that piston is placed at TDC position in compression stroke.

Caution

Do not turn the bolt in C.C.W. direction to prevent from camshaft bolt looseness.

Valve clearance inspection and adjustment.



Check & adjust valve clearance with feeler gauge.

Valve clearance (IN/EX): 0.12 ± 0.02 mm

Loosen fixing nut and turn the adjustment nut for adjustment.

Caution

Re-check the valve clearance after tightened the fixing nut.



Carburetor Idle Speed Adjustment

Caution

- Inspection & adjustment for idle speed have to be performed after all parts in engine that needed adjustment have been adjusted.
- Idle speed check and adjustment have to be done after engine is being warm up. (It is enough that operates engine from stop to running for 10 minutes.)



Park the motorcycle with main stand and warm up engine.

Connect tachometer (the wire clamp of tachometer is connected to the high tension cable).

Open carburetor cover from the luggage box.

Turn the throttle valve stopper screw to specified idle speed.

Specified idle speed: 1600 ± 100 rpm




Emission adjustment in idle speed

Warm up the engine for around 10 minutes and then conduct this adjustment.

1. Connect the tachometer onto engine.
2. Adjust the idle speed adjustment screw and let engine runs in 1600 ± 100 rpm.
3. Insert the exhaust sampling pipe of exhaust analyzer into the front section of exhaust pipe. Adjust the air adjustment screw so that emission value in idle speed is within standard.
4. Slightly accelerate the throttle valve and release it immediately. Repeat this for 2~3 times.
5. Read engine RPM and value on the exhaust analyzer. Repeat step 2 to step 4 procedures until measured value within standard.

Emission standard **CO:** below 2.5~3.5%
 HC: below 2000ppm



Ignition System

Caution

- C.D.I ignition system is set by manufacturer so it can not be adjusted.
- Ignition timing check procedure is for checking whether CDI function is in normal or not.

Remove right side cover.

Remove ignition timing hole cap located in front upper side of engine right cover.

Connect tachometer and ignition lamp.

Start engine.

As engine in idle speed: 1600 rpm, aim at the mark "F" with the ignition lamp. Then, it is means that ignition timing is correct.

Increase engine speed to 6000 rpm to check ignition advance degree. If indent is located within the ignition advance degrees, it is means that the ignition advance degree is in normal.

If ignition timing is incorrect, check CDI set, pulse rotor and pulse generator. Replace it if malfunction of these parts is found.



Cylinder Compression Pressure

Warm up engine.

Turn off the engine.

Remove the trunk.

Remove the central cover.

Remove spark plug cap and spark plug.

Install compression gauge.

Full open the throttle valve, and rotate the engine by means of starter motor.

Caution

Rotate the engine until the reading in the gauge no more increasing.

Usually, the highest pressure reading will be obtained in 4~7 seconds.

Compression pressure: $12 \pm 0.2 \text{ Kg/cm}^2$

Check following items if the pressure is too low:

- Incorrect valve clearance.
- Valve leaking.
- Cylinder head leaking, piston, piston ring and cylinder worn out.



If the pressure is too high, it means carbon deposits in combustion chamber or piston head.



Drive Belt

Remove mounting bolt located under air cleaner.
Remove Kick Stater Arm Ass'y.
Remove 3 bolts of the engine left side cover and the cover.
Check if the belt is crack or worn out.
Replace the belt if necessary or in accord with the periodical maintenance schedule to replace it.


Width limit: 19.5mm or above



Brake System (Front Disk Brake)

Brake System Hose

Make sure the brake hoses for corrosion or leaking oil.




Brake Fluid

Check brake fluid level in the brake fluid reservoir. If the level is lower than the LOWER limit, add brake fluid to UPPER limit. Also check brake system for leaking if low brake level found.

Caution

- In order to maintain brake fluid in the reservoir in horizontal position, do not remove the cap until handle stop.
- Do not operate the brake lever after the cap had been removed. Otherwise, the brake fluid will spread out if operated the lever.
- Do not mix non-compatible brake fluid together.



Filling Out Brake Fluid

Tighten the drain valve, and add brake fluid. Operate the brake lever so that brake fluid contents inside the brake system hoses.

Air Bleed Operation

Connect a transparent hose to draining valve. Hold the brake lever and open air bleeding valve. Perform this operation alternative until there is no air inside the brake system hoses.

Caution

Before closing the air bleed valve, do not release the brake lever.

Added Brake Fluid

Add brake fluid to UPPER limit lever. Recommended brake fluid: DOT3 or DOT4 WELL RUN brake fluid.

Caution

Never mix or use dirty brake fluid to prevent from damage brake system or reducing brake performance.

Brake Lining Wear

The indent mark on brake lining is the wear limitation. Replace the brake lining if the wear limit mark closed to the edge of brake disc.

Caution





It is not necessary to remove brake hose when replacing the brake lining.

Remove the brake clipper bolt, and take out the clipper.

Caution

Do not operate the brake lever after the clipper removed to avoid clipping the brake lining.

Pry out the brake lining with a flat driver if lining is clipped.



4. MAINTENANCE INFORMATION



Make sure the brake lining condition. Replace the lining if the brake lining wear limitation groove close to the brake disc.

Brake Lining Replacement

Compress the caliper and let the brake lining out of the caliper mounting plate. Compress the brake lining locking spring. Remove the inner brake lining firstly and then remove the outer brake lining.

Compress the brake caliper at first as installation. Install the inner brake lining firstly, and then install the outer brake lining.



⚠ Caution

In order to maintain brake power balance, the brake lining must be replaced with one set.

Brake Light Switch/Starting Inhibitor Switch

The brake lamp switch is to light up brake lamp as brake applied.

Make sure that electrical starter can be operated only under brake applying.



Head light Beam Distance

Turn on main switch

Head light beam adjustment. Turn the headlight adjustment screw to adjust headlight beam high.


⚠ Caution

- To adjust the headlight beam follows related regulations.
- Improper headlight beam adjustment will make in coming driver dazzled or insufficient lighting.




Clutch Disc Wear

Run the motorcycle and increase throttle valve opening gradually to check clutch operation. If the motorcycle is in forward moving and shaking, check clutch disc condition. Replace it



Side Stand

Check side stand spring for damage or looseness. Press down side stand and pull it with spring gauge. If gauge reading is over 2 kg, it means that the spring capacity is in normal. Check if side stand set is operated smoothly. Make sure that side stand is no bending or deformation.




Cushion

Warning

- Do not ride the motorcycle with poor cushion.
- Looseness, wear or damage cushion will make poor stability and drive-ability.


Front cushion

Press down the front cushion for several times to check its operation. Check if it is damaged. Replace relative parts if damage is found. Tighten all nuts and bolts.



Rear Cushion

Press down the front cushion for several times to check its operation. Check if it is damaged. Replace relative parts if damage is found. Park motorcycle with main stand. Turn the rear wheel forcefully and check if engine bracket bushing is worn out. Replace the bushing if looseness is found. Tighten all nuts and bolts.



Nuts, Bolts Tightness

Perform periodical maintenance in accord with the Periodical Maintenance Schedule.

Check if all bolts and nuts on the frame are tightened securely.

Check all fixing pins, snap rings, hose clamps, and wire holders for security.

Wheel/Tire

Caution

Tire pressure check should be done as cold engine.

Check if tire surface is ticked with nails, stones or other materials.

Appointed tire pressure



Tire size		Front tire	Rear tire
Tire pressure as cold engine (Kg/cm ²)	Load for under 90 Kg	1.75	2.25
	Full loaded	1.75	2.5

Check if front and rear tires' pressure is in normal. Measure tire thread depth from tire central surface.

Replace the tire if the depth is not come with following specification:

Front tire: 1.5 mm

Rear tire: 2.0 mm



Steering Handle Top Bearing


Caution

Check all wires and cables if they are interfered with the rotation of steering handle bar.

Lift the front wheel out of ground.


Turn handle from right to left alternative and check if turning is smoothly.

If handle turning is uneven and bending, or the handle can be operated in vertical direction, then adjust the handle top bearing.



Notes:

Precautions in Operation	5-2	Engine Oil Strainer Clean	5-3
Troubleshooting	52	Oil Pump	5-4
Engine Oil	5-3	Gear Oil	5-7




Precautions in Operation

General Information:

- This chapter contains maintenance operation for the engine oil pump and gear oil replacement.

Specifications

Engine oil quantity Disassembly: 1000 cc
 Change: 900 cc
 Oil viscosity SAE 20W-50 (Recommended
 King serial oils)
 Gear oil Disassembly: 150 cc
 Change: 120 cc
 Gear oil viscosity SAE 90
 (Recommended SYM Hypoid gear oils)



Unit: mm

Items		Standard (mm)	Limit (mm)
Oil pump	Inner rotor clearance	0.15	0.20
	Clearance between outer rotor and body	0.15~0.20	0.25
	Clearance between rotor side and body	0.04~0.09	0.12

Torque value

Torque value oil strainer cap 1.5~3.0kgf-m
 Gear oil drain plug 1.0~1.5kgf-m
 Gear oil inspection bolt 1.0~1.5kgf-m
 Oil pump connection bolt 0.8~1.2kgf-m

Troubleshooting

Low engine oil level

- Oil leaking
- Valve guide or seat worn out
- Piston ring worn out

Dirty oil

- No oil change in periodical
- Cylinder head gasket damage
- Piston ring worn out

Low oil pressure

- Low engine oil level
- Clogged in oil strainer, circuits or pipes
- Oil pump damage

Engine Oil

Turn off engine, and park the motorcycle in flat surface with main stand.

Check oil level with oil dipstick

So not screw the dipstick into engine as checking.

If oil level is nearly low level, fill out recommended oil to upper level.

Oil Change

Caution


Drain oil as engine warmed up so that make sure oil can be drained smoothly and completely.

Place a oil pan under the motorcycle, and remove oil drain bolt.

After drained, make sure washer can be re-used.

Install oil drain bolt.

Torque value : 1.9~2.5kgf-m



Engine Oil Strainer Clean

Drain engine oil out.

Remove oil strainer and spring.

Clean oil strainer.

Check if O-ring can be re-used.


Install oil strainer and spring.

Install oil strainer cap.

Torque value : 1.9~2.5kgf-m

Add oil to crankcase (oil viscosity SAE 20W-50)

Recommended using King serial oil.




Engine oil capacity: 0.9L when replacing

Install dipstick, start the engine for running several minutes.

Turn off engine, and check oil level again.

Check if engine oil leaks.




Oil Pump


Oil Pump Removal

Remove generator and starting gear. (Refer to chapter 10).

Remove snap ring and take out oil pump.



Make sure that pump shaft can be rotated freely.
Remove 3 bolts on the oil pump, and then remove oil pump.



Oil Pump Disassembly

Remove the screws on oil pump cover and disassemble the pump as illustration shown.



Oil Pump Inspection

Check the clearance between oil pump body and outer rotor.

Limit: 0.25 mm



Check clearance between inner and outer rotors.

Limit: 0.20 mm




Check clearance between rotor side face and pump body

Limit: 0.12 mm




Oil Pump Re-assembly

Install inner and outer rotors into the pump body
Align the indent on driving shaft with that of inner rotor. Install the driving shaft
Install fixing pin



Install the oil pump cover and fixing pin properly



5. LUBRICATION SYSTEM



Oil Pump Installation

Install the oil pump, and then tighten bolts.

Torque value : 0.8~1.2kgf-m



Make sure that oil pump shaft can be rotated freely.



Install oil pump driving gear and then install snap ring onto oil pump shaft.



Install starting gear and generator.
(Refer to chapter 10)



Gear Oil

Oil level inspection

Park the motorcycle on flat surface with main stand.

Turn off engine and remove oil inspection bolt.



Gear lubrication oil quantity has to be measured with measure device.

If oil level is too low, add gear oil. Recommended using King series oil.

Install oil inspection bolt.



Gear Oil Change

Remove oil level inspection bolt.

Remove drain plug and drain oil out.

Install the drain plug after drained.

Torque value: 1.0~1.4kgf-m

Make sure that the drain plug washer can be re-used.

Add oil to specified quantity from the inspection hole.

Gear Oil Quantity: 120^{CC} when replacing

Make sure that the bolt washer can be re-used, and install the bolt.


Start engine and run engine for 2-3 minutes.

Turn off engine and make sure that oil level is in correct level.

Make sure that no oil leaking.

Notes:

Precautions in Operation.....6-2	Auto By-Starter 6-7
Trouble Diagnosis.....6-3	Float Chamber..... 6-8
Carburetor removal.....6-4	Fuel Tank..... 6-10
Vacuum chamber 6-4	Air Cleaner..... 6-11
Air Cut-Off Valve 6-6	



Precautions in Operation

General Information

Warning

Gasoline is a low ignition point and explosive materials, so always work in a well-ventilated place and strictly prohibit flame when working with gasoline.

Cautions

- Do not bend off throttle cable. Damaged throttle cable will make unstable drive-ability.
- When disassembling fuel system parts, pay attention to O-ring position, replace with new one as re-assembly
- There is a drain screw in the float chamber for draining residual gasoline.
- Do not disassemble auto by-starter and air cut valve arbitrarily.

Specification

ITEM	VS2
Carburetor diameter	22.1 mm
I.D. number	VE025A
Fuel level	17.5 mm
Main injector	#100
Idle injector	#38
Idle speed	1600±100 rpm
Throttle handle clearance	2~6 mm
Pilot screw	2 1/2 turns

Tool

Special service tools

Vacuum/air pressure pump
Fuel level gauge

Trouble Diagnosis

Poor engine start

- No fuel in fuel tank
- Clogged fuel tube
- Too much fuel in cylinder
- No spark from spark plug(malfunction of ignition system)
- Clogged air cleaner
- Malfunction of auto by-starter
- Malfunction of throttle operation

Mixture too lean

- Clogged fuel injector
- Vacuum piston stick and closed
- Malfunction of float valve
- Fuel level too low in float chamber
- Clogged fuel tank cap vent
- Clogged fuel filter
- Obstructed fuel pipe
- Clogged air vent hose
- Air existing in intake system

Stall after started

- Malfunction of auto by-starter
- Incorrect ignition timing
- Malfunction of carburetor
- Dirty engine oil
- Air existing in intake system
- Incorrect idle speed

Mixture too rich

- Clogged air injector
- Malfunction of float valve
- Fuel level too high in float chamber
- Malfunction of auto by-starter
- Dirty air cleaner

Rough idle

- Malfunction of ignition system
- Incorrect idle speed
- Malfunction of carburetor
- Dirty fuel

Intermittently misfire as acceleration

- Malfunction of ignition system

Late ignition timing

- Malfunction of ignition system
- Malfunction of carburetor

Power insufficiency and fuel consuming


- Fuel system clogged
- Malfunction of ignition system

6. FUEL SYSTEM




Carburetor removal

Remove the luggage box.
Loosen the adjustment nut and fixing nut of throttle valve cable, and release the cable from carburetor.
Disconnect automatic by-starter connector.
Release the clamp strip of air cleaner.



Remove fuel pipe, vacuum hose.
Release the clamp strip of carburetor insulator.



Vacuum chamber

Removal

Loosen drain screw, and drain out residual fuel in float chamber.
Remove 2 screws of vacuum chamber cover and the cover.




Remove compress spring and vacuum piston.



Check if the vacuum piston for wear out, crack or other damage.
Check if the diaphragm for damage or crack.

Installation

Install needle, spring and needle seat to vacuum piston.



Install vacuum piston to carburetor body and align the indent on the diaphragm.
Install compress spring.



Install vacuum chamber cover and tighten 2 screws.

Caution

- Do not damage vacuum diaphragm.
- When tightening the vacuum chamber screw, hold down vacuum piston.



Air Cut-Off Valve

Inspection

Disconnect vacuum hose and air vent hose from the air cut-off valve.

Connect a hose from vacuum hose connector to vacuum pump.

Connect air pump to air vent hose.

Apply with specified vacuum to air cut-off valve.

Vacuum value: 420~500 mm-Hg

Pump compressed air from air pump to air vent hose.



Caution

The vacuum can not be over 600 mm-Hg. Or the air cut-off will be damaged.

If the valve is in normal, it will restrict air-flow.

If air-flow is no restriction, replace carburetor assembly.



Auto By-Starter

Inspection

Turn off engine and waiting for over 10 minutes for cooling.

Check resistance across the two terminals of the auto by-starter.

Resistance value: Max. 10Ω (Measured after engine stopped for more than 10 minutes)

Replace the auto starter with a new one if resistance value exceeds standard.

Remove carburetor allow it to cool off for 30 minutes.



Connect a pressure tester from air pump.

Connect by-starter circuit.

Pump compressed air to the circuit.


Replace the auto by-starter if the circuit clogged.

Connect battery posts (12V) to starter's connectors. After 5 minutes, test the by-starter circuit with compressed air. If air flows through the circuit, then, replace the starter.



Removal

Remove fixing plate screw, and then remove the plate and auto by-starter from carburetor.




Valve inspection

Check if auto by-starter and valve needle for damage or wear out.

Installation

Install auto by-starter to the bottom of carburetor body.

Install fixing plate to the upper groove of auto by-starter, and install its flat surface to carburetor. Install screw and tighten it.



6. FUEL SYSTEM



Float Chamber

Disassembly

Remove 4 mounting screws and remove float chamber cover.

Remove the float pin and float.



Checking

Check float valve and valve seat for damage, blocking.

Check float valve for wearing, and check valve seat face for wear, dirt.

Caution

In case of worn out or dirt, the float valve and valve seat will not tightly close causing fuel level to increase and as a result, fuel flooding. A worn out or dirty float valve must be replaced with a new one.




Remove main jet, fuel needle jet holder, needle jet, slow jet, pilot screw.


Caution

Take care not to damage jets and adjust screw.

- Before removing adjustment screw, turn it all the way down and note the number of turns.
- Do not turn to adjust screw forcefully to avoid damaging valve seat face.



Clean jets with cleaning fluid. Then use compressed air to blow the dirt off. Blow carburetor body passages with compressed air.



Assembly

Install main jet, fuel needle jet holder, fuel needle jet slow jet and pilot screw.

Caution

Set the pilot screw in according to number of turns noted before it was removed.

Install the float valve, float, and float pin.

Checking fuel level

Caution

- Check again to ensure float valve, float for proper installation.
- To ensure correct measurement, position the float meter in such a way so that float chamber face is vertical to the main jet.

Fuel level: 20.5 mm

Installation of carburetor

Install carburetor in the reverse order of removal. Following adjustments must be made after installation.

- Throttle cable adjustment.
- Idle adjustment

Adjustment of pilot screw

Caution

- Pilot screw was set at factory, so no adjustment is needed. Note the number of turns it takes to screw it all the way in for ease of installation.
- The main stand must be used to support the motorcycle to perform the adjustments.

Use a tachometer when adjusting engine RPM. Screw in adjustment screw gently, then back up to standard turns.

Standard turns: $2 \pm 1/2$ (1 1/2 ~ 2 1/2) turns

Engine warm up, adjust the stopper screw of throttle valve to standard RPM.





Idle speed rpm: 1600 ± 100 rpm

Connect the hose of exhaust analyzer to exhaust front end. Press test key on the analyzer.

Adjust the pilot screw and read CO reading on the analyzer

CO standard value: 1.0~1.5 %

Accelerate in gradual increment make sure rpm and CO values are in standard value after engine running in stable. If rpm and CO value fluctuated, repeat the procedures described above for adjusting to standard value.



6. FUEL SYSTEM



Fuel Tank

Fuel unit removal

Open the seat.
Remove the luggage box (6 bolts and 1 screw).
Remove rear carrier (4 bolts).
Remove body cover.
Disconnect fuel unit connector.
Remove fuel unit.

Caution

- Do not bend the float arm of fuel unit
- Do not fill out too much fuel to fuel tank.


Fuel unit inspection. (Refer to electrical equipment chapter 16)

Fuel unit installation

Install the gauge in the reverse order of removal.


Caution

Do not forget to install the gasket of fuel unit or damage it.



Fuel tank removal


Remove the Fuel cut valve assembly and Fuel tube.



Remove fuel tank (6 screws).

Installation


Install the tank in the reverse order of removal.



Air Cleaner

Removal

Open the seat.
Remove the luggage box (6 bolts and 1 screw).
Loosen the clamp strip of air cleaner.
Remove the Vapor hose.
Remove the Air cleaner (2 bolts).




Installation

Install the tank in the reverse order of removal.



Cleaning air cleaner element


Remove air cleaner cover (6 screws).



Remove the Air cleaner element. (Screw×6)
With compressed air clean dirty around the element. Replace it if it is too dirty to clean.

Caution

The air cleaner element is made of paper so do not soap it into water or wash it with water.



Notes:

Precautions in Operation 7-1	Removal of Engine Hanger Bush 7-6
Removal of Engine 7-2	Engine Hanger Installation 7-7
Engine Hanger removal.....7-5	Engine Installation.....7-7

Precautions in Operation

General Information

- The engine has to be supported with special service tools that can be lifted or adjustable.
- The following parts can be serviced as engine mounted on frame.
- Carburetor.
- Driving pulley, driving belt, clutch, and driving disc assembly.
- Final gear reduction mechanism.

Specification

Item		Capacity
Engine oil capacity	Replacement	900 ^{cc}
	Disassembly	1000 ^{cc}
Gear oil capacity	Replacement	120 ^{cc}
	Disassembly	150 ^{cc}

7

Torque Value

Engine mounting bolt	4.0~5.0kgf-m
Rear cushion upper connection bolt	3.5~4.5kgf-m
Rear cushion under connection bolt	2.4~3.0kgf-m
Engine hanger bolt	4.0~5.0kgf-m
Rear wheel axle nut	11.0~13.0kgf-m

7. ENGINE REMOVAL



Removal of Engine

Open seat and remove the luggage box (6 bolts and 1 screw).

Remove rear carrier (4 bolts).

Remove battery cover (2 screws).

Remove battery negative (-) position.

Remove battery positive (+) position.

Remove tail light connector.

Remove right and left body cover (2 bolts).

Disconnect the auto by-starter wire connector.




Disconnect A.C.G wire connectors.

Remove starter motor wire from relay.

Remove spark plug cap.

Remove fuel pipe, vacuum tube and throttle valve wire from carburetor.


Loosen the screw of air cleaner duct strip, and then remove the duct.




Remove right and left body cover.
Remove right and left pillion step ass'y




Remove the fuel pump.



Remove the muffler (3 bolts, 2 nuts).




Remove rear inner fender



7. ENGINE REMOVAL



Remove the mounting bolt of right-rear cushion.
Remove the rear fork mounting bolt. (2 bolts)
Remove rear wheel axle mounting nut.




Remove rear fork and collars.



Remove rear wheel.





Remove the mounting bolt of left-rear cushion.



Remove the right and left side engine hanger mounting bolts and nuts, then remove engine.


Caution

- Support engine and frame separately with special supporters to prevent from engine or frame falling down.




Engine Hanger removal

Remove the engine mounting bolt and nut, then remove engine hanger.



Removal of Engine Hanger Bush

Check if engine hanger bush and cushion rubber bush for damage.



Pressing out


If engine hanger and the rear cushion rubber bush damaged. Then with the bush remover/presser, $\varnothing$ 30mm & $\varnothing$ 22mm to press the bush out, and replace it with new one.

Engine hanger bush: $\varnothing$ 30mm

Rear cushion bush: $\varnothing$ 22mm




Place the detent section of the bush remover toward the bush, and drive both the pressing ring and bolt in to press the bush out.



Pressing In

Place the flat section of the remover toward the bush, and then drive the bush, pressing ring, and bolt in to install the bush.



Engine Hanger Installation

Install engine hanger onto engine.

Install engine mounting bolts & nuts and then tighten the nuts.

Torque value: 4.0~5.0kgf-m

Engine Installation


Check if the bush of engine hanger parts and cushion for damage.

Install engine in the reverse procedures of removal.



Caution

- Pay attention of foot & hand safety as engine installation to avoid hurting.
- Do not bend or twist wires.
- Cables wires have to be routed in accordance with normal layout.
- Small-end bearing collar has to forward to inside (bearing) as assembling the rear fork.



Engine hanger Bolt:

Torque value: 4.0~5.0kgf-m

Rear cushion bolt:

Torque value: upper : 3.5~4.5kgf-m
under : 2.4~3.0kgf-m


Rear wheel axle nut:

Torque value: 11.0~13.0kgf-m

Notes:

Mechanism Diagram	8-1	Valve Stem Replacement.....	8-8
Precautions in Operation	8-2	Valve Seat Inspection and Service...	8-9
Troubleshooting.....	8-3	Cylinder Head Reassembly	8-11
Cylinder Head Removal.....	8-4	Cylinder Head Installation	8-12
Cylinder Head Disassembly.....	8-6	Valve Clearance Adjustment.....	8-14
Cylinder Head Inspection	8-7		

Mechanism Diagram



Precautions in Operation

General Information

- This chapter is contained maintenance and service for cylinder head, valve, and camshaft as well as rocker arm.
- Cylinder head service can be carried out when engine is in frame.

Specification

Item			Standard	Limit
Compression pressure			12+/-0.2 kg/cm2	---
Camshaft	Height of cam lobe	Intake	25.768~25.920	25.37
		Exhaust	25.755~25.531	25.36
Rocker arm	ID of valve rocker arm		10.000~10.015	10.10
	OD of valve rocker arm shaft		9.972~9.987	9.910
Valve	OD of valve stem	Intake	4.970~4.980	4.900
		Exhaust	4.955~4.970	4.900
	Guide seat		5.000~5.012	5.030
	Clearance between valve stem and guide	Intake	0.010~0.037	0.080
		Exhaust	0.030~0.062	0.100
	Free length of valve spring		35.000	31.500
	Valve seat width		1.000	1.8
Tilt angle of cylinder head			---	0.05

Torque Value

Cylinder head bolt	2.0~2.4kgf-m
Cylinder head Nut	2.0~2.4kgf-m
Sealing bolt of cam chain auto-tensioner	0.8~1.2kgf-m
Bolt of cam chain auto-tensioner	1.2~1.6kgf-m
Cam sprocket cover bolts	0.8~1.2kgf-m
Cam sprocket bolt	0.8~1.2kgf-m
Spark plug	1.0~1.2kgf-m

Tools

Special service tools

Valve reamer: 5.0mm
 Valve guide driver: 5.0mm
 Valve spring compressor

Troubleshooting

Engine performance will be effect by troubles on engine top parts. The trouble usually can be determined or by performing cylinder compression test and judging the abnormal noise generated.

Low compression pressure

1. Valve

- Improper valve adjustment
- Burnt or bent valve
- Improper valve timing
- Valve spring damage
- Valve carbon deposit.

2. Cylinder head

- Cylinder head gasket leaking or damage
- Tilt or crack cylinder

3. Piston

- Piston ring worn out.

High compression pressure


- Too much carbon deposit on combustion chamber or piston head

Noise

- Improper valve clearance adjustment
- Burnt valve or damaged valve spring
- Camshaft wear out or damage
- Chain wear out or looseness
- Auto-tensioner wear out or damage
- Camshaft sprocket
- Rocker arm or rocker arm shaft wear out

Cylinder Head Removal

Remove seat, luggage box and body cover.
Remove engine. (Refer to chapter 5)
Remove the clamp strip bolt of carburetor, and disconnect vacuum tube from the carburetor insulator.




Remove holing cap for the adjustment bolt of cam chain tensioner, and then loosen the tensioner by turning a flat-driver in C.W direction.




Remove the side cover mounting bolts of cylinder head, and then take out the side cover.
Remove the A.I.A.C Tube connect to the air cleaner connecting tube and the air pipe.
Remove the A.I.C.V Tube B, the A.I.C.V reed valve joint tube and A.I.C.V.P.B joint tube.




Remove cam sprocket bolts and then remove the sprocket by prying chain out.




Remove the 2 cylinder head mounting bolts from cylinder head right side, and then remove 4 nuts and washers from cylinder head upper side.



Remove the A.I.C.V Ass'y take out side.
Remove the cylinder head as shown figure.
Remove the Reed valve Comp.




Remove 2 bolts of carburetor insulator and then take the insulator out.



Remove cylinder head gasket and 2 dowel pins.
Remove chain guide.
Clean up residues from the matching surfaces of cylinder and cylinder head.

Caution

- Do not damage the matching surfaces of cylinder and cylinder head.
- Avoid residues of gasket or foreign materials falling into crankcase as cleaning.



8. CYLINDER HEAD/VALVE




Cylinder Head Disassembly

Remove the hosing cap of intake & exhaust valve clearance adjustment. There are 6 bolts. Then, remove the cap.



Remove the rocker arm pin stopper plate, and then screw a 5mm bolt into the rocker arm pin. Finally, remove the pin and the rocker arm.

Screw a 6 mm bolt into cam sprocket mounting bolt hole, and then pull the camshaft out.



Use a valve compressor to press the valve spring.



Caution

- In order to avoid losing spring elasticity, do not press the spring too much. Thus, press length is based on the valve cotter in which can be removed.

Special Service Tool:

Valve spring remover (SYM-1471110)

Valve spring installer (SYM-1471120)




Remove valve stem guide seal.
Clean carbon deposits in combustion chamber.
Clean residues and foreign materials on cylinder head matching surface.



Caution


Do not damage the matching surface of cylinder head.



Cylinder Head Inspection

Check if spark plug and valve holes are cracked.
Measure cylinder head warp with a straightedge and thickness gauge.


Service limit: 0.5 mm



Valve spring free length

Measure the free length of intake and exhaust valve springs.

Service limit: 31.50 mm




Valve stem

Check if valve stems are bend, crack or burn.
Check the operation condition of valve stem in valve guide, and measure & record the valve stem outer diameter.

Service Limit: IN: 4.90 mm

EX: 4.90 mm



Valve guide

Caution

Before measuring the valve guide, clean carbon deposits with reamer.

Tool: 5.0 mm valve guide reamer


Measure and record each valve guide inner diameters.

Service limit: 5.03 mm

The difference that the inner diameter of valve guide deducts the outer diameter of valve stem is the clearance between the valve stem and valve guide.

Service Limit: IN→0.08 mm

EX→0.10 mm



8. CYLINDER HEAD/VALVE



Caution

If clearance between valve stem and valve guide exceeded service limit, check whether the new clearance that only replaces new valve guide is within service limit or not. If so, replace valve guide.

Correct it with reamer after replacement.
If clearance still exceeds service limit after replaced valve guide, replace valve stem too.

Caution

It has to correct valve seat when replacing valve guide.

Valve Stem Replacement

Heat up cylinder head to 100~150°C with heated plate or toaster.

Caution

- Do not let torch heat cylinder head directly. Otherwise, the cylinder head may be deformed as heating it.
- Wear on a pair of glove to protect your hands when operating.

Hold the cylinder head, and then press out old valve guide from combustion chamber side.

Tool: Valve guide driver: 5.0 mm

Caution

- Check if new valve guide is deformation after pressed it in.
- When pressing in the new valve guide, cylinder head still have to be kept in 100~150°C.

Adjust the valve guide driver and let valve guide height is in 13 mm.

Press in new valve guide from rocker arm side.

Tool: Valve guide driver: 5.0 mm





Wait for the cylinder head cooling down to room temperature, and then correct the new valve guide with reamer.

Caution

- Using cutting oil when correcting valve guide with a reamer.
- Turn the reamer in same direction when it be inserted or rotated.

Correct valve seat, and clean up all metal residues from cylinder head.

Tool: Valve guide reamer: 5.0 mm



Valve Seat Inspection and Service

Clean up all carbon deposits onto intake and exhaust valves.

Apply with emery slightly onto valve contact face.

Grind valve seat with a rubber hose or other manual grinding tool.

Caution

- Do not let emery enter into between valve stem and valve guide.
- Clean up the emery after corrected, and apply with engine oil onto contact faces of valve and valve seat.

Remove the valve and check its contact face.

Caution

Replace the valve with new one if valve seal is roughness, wear out, or incomplete contacted with valve seat.

Valve seat inspection

If the valve seat is too width narrow or rough, correct it.

Valve seat width

Service limit: 1.6mm

Check the contact condition of valve seat.

Valve seat grinding

The worn valve seat has to be ground with valve seat chamfer cutter.





Refer to operation manual of the valve seat chamfer cutter.

Use 45° valve seat chamfer cutter to cut any rough or uneven surface from valve seat.

Caution


After valve guide had been replaced, it has to be ground with 45° valve seal chamfer cutter to correct its seat face.

Use 32° cutter to cut a quarter upper past out.



8. CYLINDER HEAD/VALVE

Use 60° cutter to cut a quarter lower past out.
Remove the cutter and check new valve seat.




Use 45° cutter to grind the valve seat to specified width.

Caution

Make sure that all roughness and uneven faces had been ground.


Grind valve seat again if necessary.



Coat the valve seat surface with red paint.
Install the valve through valve guide until the valve contacting with valve seat, slightly press down the valve but do not rotate it so that a seal track will be created on contact surface.


Caution

The contact surfaces of valve and valve seat are very important to the valve sealing capacity.




If the contact is too high grind the valve seat with 32° cutter.
Then, grind the valve seat to specified width.

If the contact surface too low, grind the valve seat with 60° cutter.
Then, grind the valve seat to specified width.



After the valve seat ground, coat valve seat surface with emery and then slightly press the ground surface.
Clean up all emery coated onto cylinder and valve after ground.




Cylinder Head Reassembly

Lubricate valve stem with engine oil, and then insert the valve into valve guide.
Install new valve stem oil seal.
Install valve springs and retainers.

Caution

The closed coils of valve spring should face down to combustion chamber.



Use valve spring compressor to press valve spring.

Caution

In order to avoid damaging the valve stem and the cylinder head, in the combustion chamber place a rag between the valve spring remover/installer as compressing the valve spring directly.

Special Service Tool:


Valve spring remover (SYM-1471110)

Valve spring installer (SYM-1471120)

Tap valve stem to make valve retainer and valve stem sealing properly.

Caution

Place and hold cylinder head on to working table so that can prevent from valve damaged.




8. CYLINDER HEAD/VALVE




Cylinder Head Installation

Install a new O-ring into the indent of carburetor insulator, and then install the insulator onto cylinder head with 2 bolts.




Install camshaft into cylinder head, and align rocker pin with rocker arm pin hole. Then, insert the rocker arm pin.
Install rocker arm pin mounting plate.




Clean up all residues and foreign materials onto the matching surfaces of both cylinder and cylinder head.
Install chain guide.
Install 2 set pins and cylinder head gasket.

Caution

Do not damage the matching surfaces of cylinder and cylinder head.
Avoid residues of gasket or foreign materials falling into crankcase as cleaning.



Loosen the tensioner by turning a flat-driver in C.W direction.
Install cylinder head.



Tighten 4 nuts and washers on the cylinder head upper side, and then tighten 2 cylinder head mounting bolts of cylinder head side cover. Install Reed valve and A.I.C.V Unit.

Torque value: 2.0~2.4kgf-m

Install and tighten spark plug

Torque value: 2.0~2.4kgf-m

Caution

This model is equipped with more precision 4-valve mechanism so its tighten torque can not be exceeded standard value in order to avoid causing cylinder head deformation, engine noise and leaking so that motorcycle's performance be effected.

Install cam chain on to sprocket and align the timing mark on the sprocket with that of cylinder head.




Align sprocket bolt hole with camshaft bolt hole. Tighten the sprocket mounting bolt.

Caution

Make sure timing marks are matched.

Loosen sprocket chain tensioner and let it contact with chain plate tightly. Tighten the bolt cap of tensioner adjustment hole.

Install carburetor insulator onto carburetor and tighten clamp strip bolt. Install the vacuum hose of carburetor insulator.



8. CYLINDER HEAD/VALVE



Valve Clearance Adjustment

Loosen valve clearance adjustment nuts and bolts located on valve rocker arm.

Measure and adjust valve clearance with feeler gauge.

After valve clearance had been adjusted to standard value, hold adjustment bolt and then tighten the Adjustment nut.

Standard Value: IN 0.12 ± 0.02 mm
EX 0.12 ± 0.02 mm

Install the valve clearance adjustment holding cap. (3 bolts)

Caution

The gasket is paper type. In case of broken, replace it and clean the Remnant gasket.

Start the engine after assembly. Remove the intake valve adjustment holding cap and make sure that engine oil flows onto the cylinder head.

Stop the engine after confirmed, and then install the intake valve adjustment holding cap.

Install the seat, luggage box and the body cover.

Caution


- If lubricant does not flow to cylinder head, engine components will be worn out seriously. Thus, it must be confirmed.
- When checking lubricant flowing condition, run the engine in idle speed. Do not accelerate engine speed.



Notes:

Mechanism Diagram	9-1	Piston Removal	9-4
Precautions in Operation	9-2	Piston Ring Installation	9-6
Trouble Diagnosis.....	9-2	Piston Installation	9-7
Cylinder Removal.....	9-3	Cylinder Installation	9-7

Mechanism Diagram



Precautions in Operation

General Information

- Both cylinder and piston service cannot be carried out when engine mounted on frame.

Specification

Unit : mm

Item			Standard	Limit
Cylinder	ID		57.400~57.415	57.416
	Bend		-	0.050
Piston/ Piston ring	Clearance between piston rings	Top ring	0.015~0.050	0.090
		2 nd ring	0.015~0.050	0.090
	Ring-end gap	Top ring	0.150~0.300	0.500
		2 nd ring	0.300~0.450	0.650
		Oil ring side rail	0.200~0.700	-
	OD of piston		57.400~57.405	57.390
	Clearance between piston and cylinder		0.010~0.040	0.100
	ID of piston pin boss		15.002~15.008	15.040
OD of piston pin			14.960~15.000	14.930
Clearance between piston and piston pin			0.002~0.014	0.020
ID of connecting rod small-end			15.016~15.034	15.060

Item		Standard	Limit
Cylinder	ID	57.395~57.415	57.416
Piston	OD of piston	57.385 ~57.405	57.300

Trouble Diagnosis

Low or Unstable Compression Pressure

- Cylinder or piston ring worn out

Smoking in Exhaust Pipe

- Piston or piston ring worn out
- Piston ring installation improperly
- Cylinder or piston damage

Knock or Noise

- Cylinder or piston ring worn out
- Carbon deposits on cylinder head top-side
- Piston pin hole and piston pin wear out

Engine Overheat

- Carbon deposits on cylinder head top side
- Cooling pipe clogged or not enough in coolant flow

Cylinder Removal

Remove cylinder head (refer to chapter 6).

Remove cylinder.



Remove cylinder gasket and dowel pin.

Cover the holes of crankcase and cam chain with a piece of cloth.

Clean up all residues or foreign materials from the two matching surfaces of cylinder and crankcase.

Caution

- Soap the residues into solvent so that the residues can be removed more easily.




Inspection

Check if the inner diameter of cylinder is wear out or damaged.


In the 3 positions, top, center and bottom, of cylinder, measure the X and Y values respective in the cylinder.

Service limit: 57.85 mm



Check cylinder if warp.

Service limit: 0.05 mm



Piston Removal

Plug crankcase opening with a cleaning cloth to prevent from piston pin snap ring or other foreign materials falling into crankcase when disassembling.

Hold another snap ring with pliers.

Push out the piston pin from the side that not removed the snap ring.



Inspection

Measure clearance between piston ring and its grooves.

Service Limit: Top ring: 0.09 mm

2nd ring: 0.09 mm



Remove piston rings

Check if the piston rings are damaged or its grooves are worn.


Caution

Pay attention to remove piston rings because they are fragile.

Place piston rings respective into cylinder below 20 mm of cylinder top. In order to keep the piston rings in horizontal level in cylinder, push the rings with piston.


Service Limit: Top ring: 0.50 mm

2nd ring: 0.65 mm




Measure the outer diameter of piston pin by micrometer.

Service Limit: 15.04 mm



Measure the inner diameter of connecting rod small end.

Service Limit: 15.06 mm




Measure the inner diameter of piston pin hole.

Service Limit: 15.04 mm

Calculate clearance between piston pin and its hole.

Service Limit: 0.02 mm



Measure the outer diameter of piston.

⚠ Caution

The measurement position is 10 mm distance from piston bottom side, and 90° to piston pin.

Service limit : 57.68 mm

Compare measured value with service limit to calculate the clearance between piston and cylinder.



Piston Ring Installation


Clean up piston top, ring groove, and piston surface.

Install the piston ring onto piston carefully.

Place the openings of piston ring as diagram shown.

Caution

- Do not damage piston and piston rings as installation.
- All marks on the piston rings must be forwarded to up side.
- Make sure that all piston rings can be rotated freely after installed.



Piston Installation

Install piston and piston pin, and place the IN marks on the piston top side forward to intake valve.

Install new piston pin snap ring.

Caution

- Do not let the opening of piston pin snap ring align with the opening piston ring.
- Place a piece of cloth between piston and crankcase in order to prevent snap ring from falling into crankcase as operation.



Cylinder Installation

Clean up all residues and foreign materials on the matching surface of crankcase. Pay attention to not let these residues and foreign materials fall into crankcase.

Caution

Soap the residues into solvent so that the residues can be removed more easily.




Install dowel pins and new gasket.

Coat engine oil to inside of cylinder, piston and piston rings.


Care to be taken when installing piston into cylinder. Press piston rings in one by one as installation.

Caution

Do not push piston into cylinder forcefully because piston and piston rings will be damaged.




Install cylinder head (refer to Chapter 6).



Notes:

Mechanism Diagram	10-1	Driving Belt.....	10-4
Maintenance Description.....	10-2	Drive Face.....	10-6
Trouble Diagnosis	10-2	Clutch Outer/Driven Pulley.....	10-9
Left Crankcase Cover	10-3		

Mechanism Diagram



Maintenance Description

Precautions in Operation

General Information

- Drive face, clutch outer, and driven pulley can be serviced on the motorcycle.
- Driving belt and driving pulley must be free of grease.

Specification

Unit : mm

Item	Standard value (mm)	Limit (mm)
Driving belt width	19.500~20.500	18.500
ID of drive face boss	23.989~24.052	24.060
OD of drive face	23.960~23.974	23.940
OD of roller	17.920~18.080	17.400
ID of clutch outer	125.000~125.200	125.500
Thickness of clutch weight	4.000~4.100	1.200
Free length of driven pulley spring	168.900	163.700
OD of driven pulley	43.65~43.85	43.800
ID of drive face	39.000~39.025	39.060

Torque value

- Driven face nut: 5.0~6.0kgf-m
- Clutch outer nut: 5.0~6.0kgf-m

Special Service Tools

Clutch spring compressor: SYM-2301000
 Inner bearing puller: SYM-6204002
 Clutch nut wrench 39 x 41 mm: SYM-9020200
 Universal holder: SYM-2210100
 Bearing driver: SYM-9100100

Trouble Diagnosis

Engine can be started but motorcycle can not be moved

1. Worn driving Belt
2. Worn drive face
3. Worn or damaged clutch weight
4. Broken driven pulley

Insufficient horsepower or poor high speed performance

1. Worn driving belt
2. Insufficient spring force of driven pulley
3. Worn roller
4. Driven pulley operation un-smoothly

Shudder or misfire when driving

1. Broken clutch weight
2. Worn clutch weight

Left Crankcase Cover

Left crankcase cover removal

Remove body cover.

Remove kick starter arm ass'y.

Remove air cleaner ass'y (2 bolts 6×25).

Remove L. Cover fender Comp.

Remove L. Crankcase cover (8 special bolts 6×37 ass'y).




Left crankcase cover install


Install left crankcase cover in the reverse procedures of removal.



Drive face and Driven face Comp.



L. Crank case cover Comp.




Driving Belt

Removal

Remove left crankcase cover


Hold drive face with universal holder, and remove nut and drive face.



Hold clutch outer with universal holder, and remove nut and clutch outer.


⚠ Caution

- Using special service tools for tightening or loosening the nut.
- Fixed rear wheel or rear brake will damage reduction gear system.



Push the driving belt into belt groove as diagram shown so that the belt can be loosened, and then remove the driven pulley.

Remove driven pulley. Do not remove driving belt. Remove the driving belt from the groove of driven pulley.



Inspection

Check the driving belt for crack or wear. Replace it if necessary.


Measure the width of driving belt as diagram shown.

Service Limit: 18.5 mm

Replace the belt if exceeds the service limit.

⚠ Caution

- Using the genuine parts for replacement.
- The surfaces of driving belt or pulley must be free of grease.
- Clean up all grease or dirt before installation.




Installation



Caution


Pull out driven face to avoid it closing.

Install driving belt onto driven pulley.




Install the driven pulley that has installed the belt onto drive shaft.

On the drive belt another end to the movable drive face.




Install the clutch outer with universal holder, and then tighten nut to specified torque value.

Torque value: 5.0~6.0kgf-m



Install the drive face with universal holder, and then tighten nut to specified torque value.


Torque value: 5.0~6.0kgf-m




Drive Face

Removal


Remove left crankcase cover.
Hold generator flywheel with universal holder, and then remove drive face nut.
Remove drive face.




Remove driving belt and movable drive face comp from crankshaft.



Remove ramp plate.



Remove weight rollers from movable drive face.



Inspection

The weight rollers are to press movable drive face by means of centrifuge force.

Thus, if weight rollers are worn out or damaged, the centrifuge force will be effect.

Check if rollers are worn or damaged. Replace it if necessary.

Measure each roller's outer diameter. Replace it if exceed the service limit.

Service limit: 17.4 mm

Weight: 14.0 g

Check if drive face boss is worn or damaged and replace it if necessary.

Measure the outer diameter of movable drive face, and replace it if it exceed service limit.

Service limit: 23.94 mm

Measure the inner diameter of movable drive face, and replace it if it exceed service limit.

Service limit: 24.06 mm





Reassembly/installation

Install weight rollers.

Caution

The weight roller two end surfaces are not certainly same. In order to lengthen the roller life and prevented exceptionally wears the occurrence, Please end surface of the closure surface counter clockwise assembles onto movable drive face.

Install ramp plate.



10. V-BELT DRIVING SYSTEM/KICK STARTER




With 4~5g grease spreads wipes drives in the movable drive face axis hole.


Install drive face boss.

Caution

The movable drive face surface has to be free of grease. Clean it with cleaning solvent.




Install movable drive face comp. onto crankshaft.



Driven pulley installation

Press driving belt into pulley groove, and then pull the belt onto drive shaft.



Install drive face, washer and nut.

Caution


Make sure that two sides of pulley surfaces have to be free of grease. Clean it with cleaning solvent.

Hold driver face with universal holder.

Tighten nut to specified torque.

Torque value: 5.0~6.0kgf-m

Install left crankcase cover.



Clutch Outer/Driven Pulley

Disassembly

Remove drive belt and clutch outer/driven pulley. Install clutch spring compressor onto the pulley assembly, and operate the compressor to let the wrench be installed more easily.

⚠ Caution

Do not press the compressor too much.

Hold the clutch spring compressor onto bench vise, and then remove mounting nut with special service tool.

Release the clutch spring compressor and remove clutch weight and spring from driven pulley.

Remove seal collar from driven pulley.





Remove guide pin, guide pin roller, and movable driven face, and then remove O-ring & oil seal seat from movable driven face.

Inspection

Clutch outer

Measure the inner diameter of clutch outer. Replace the clutch outer if exceed service limit.


Service limit: 125.5 mm



Clutch lining

Measure each clutch weight thickness. Replace it if exceeds service limit.


Service limit: 2.0 mm



Driven pulley spring

Measure the length of driven pulley spring. Replace it if exceeds service limit.

Service limit: 163.7 mm



Driven pulley

Check following items:


- If both surfaces are damaged or worn.
- If guide pin groove is damaged or worn.

Replace damaged or worn components.

Measure the outer diameter of driven face and the inner diameter of movable driven face. Replace it if exceeds service limit.

Service limit: Outer diameter 33.94 mm

Inner diameter 34.06 mm



Driven Pulley Bearing Inspection

Check if the inner bearing oil seal is damage.


Replace it if necessary.

Check if needle bearing is damage or too big clearance. Replace it if necessary.

Rotate the inside of inner bearing with fingers to check if the bearing rotation is in smooth and silent.

Check if the bearing outer parts are closed and fixed.

Replace it if necessary.




Clutch weight Replacement

Remove snap ring and washer, and then remove clutch weight and spring from driving plate.


Caution

Some of models are equipped with one mounting plate instead of 3 snap rings.

Check if spring is damage or insufficient elasticity.




Check if shock absorption rubber is damage or deformation. Replace it if necessary.
Apply with grease onto setting pins.




Install new clutch weight onto setting pin and then push to the specified location.
Apply with grease onto setting pins.
But, the clutch block should not be greased. If so, replace it.

Caution

Grease or lubricant will damage the clutch weight and effective the block's connection capacity.




Install the spring into groove with pliers.



10. V-BELT DRIVING SYSTEM/KICK STARTER



Install snap ring and mounting plate onto setting pin.




Replacement of Driven Pulley Bearing

Remove inner bearing.

Caution


- If the inner bearing equipped with oil seal on side in the driven pulley, then remove the oil seal firstly.
- If the pulley equipped with ball bearing, it has to remove snap ring and then the bearing.



Remove snap ring and then push bearing forward to other side of inner bearing.

Place new bearing onto proper position and its sealing end should be forwarded to outside.

Apply with specified oil.




Install new inner bearing.

Caution

- Its sealing end should be forwarded to outside as bearing installation.
- Install needle bearing with hydraulic presser. Install ball bearing by means of hydraulic presser.

Install snap ring into the groove of driving face.

Align oil seal lip with bearing, and then install the new oil seal (if necessary).




Installation of Clutch OUTER/Driven Pulley


Assembly

Install new oil seal and O-ring onto movable driven face.


Apply with specified grease to lubricate the inside of movable driven face.



Install the movable driven face onto driven face.
Install the guide pin and guide pin roller.



Install the collar.




Install driving belt, spring and clutch weight COMP. into clutch spring compressor, and press down the assembly by turning manual lever until mounting nut that can be installed.

Hold the compressor by bench vise and tighten the mounting nut to specified torque with clutch nut wrench.

Remove the clutch spring compressor.

Torque value: 5.0~6.0kgf-m


Install clutch outer/driven pulley and driving belt onto driving shaft.



Notes:

Mechanism Diagram	11-1	Inspection of Final Driving Mechanism	11-4
Precautions in operation	11-2	Bearing Replacement	11-5
Trouble Diagnosis	11-2	Re-assembly of Final Driving Mechanism	11-8
Disassembly of Final Driving Mechanism	11-3		

Mechanism Diagram



Precautions in operation

Specification

Application oil: scooter gear oil

Recommended oil: KING MATE serial gear oils

Oil quantity: 100^{cc}. (100^{cc} when replacing)

Torque value

Gear box cover 1.0~1.4kgf-m

Tools

Special tools

Bearing (6203/6004UZ) driver: SYM-9620000

Bearing (6204) driver: SYM-9110400

Bearing (6301) driver: SYM-9610000

Oil seal (27*42*7) driver: SYM-9125500

Oil seal (20*32*6) driver: SYM-9120200

Inner bearing puller: SYM-6204002

Outer bearing puller: SYM-6204001

Drive shaft puller: SYM-1130000-L

Drive shaft install bush: SYM-1130010

Extension bush (long): SYM-1130031

Extension bush (short): SYM-1130032

Trouble Diagnosis

Engine can be started but motorcycle can not be moved.

- Damaged driving gear
- Burnt out driving gear

Noise


- Worn or burnt gear
- Worn gear

Gear oil leaks


- Excessive gear oil.
- Worn or damage oil seal

Disassembly of Final Driving Mechanism


Remove driven pulley.
 Drain gear oil out from gear box.
 Remove gear box cover bolts and then remove the cover and drive shaft.



Remove final gear and shaft.
 Remove counter shaft and gear.




Remove gasket and dowel pin.



Remove the drive shaft.
 In order to avoid damaging the gear box cover, in the cover place a rag between the cover and table.

Caution

- If non- essential do not remove the drive shaft from the cover upper side.
- If remove the drive shaft from the gear box cover, then its bearing has to be replaced.




11. FINAL DRIVING MECHANISM




Inspection of Final Driving Mechanism


Check if the countershaft is wear or damage.



Check if the final shaft and gear are burn, wear or damage.



Check bearings on gear box.
Rotate each bearing's inner ring with fingers.
Check if bearings can be turned in smooth and silent, and also check if bearing outer ring is mounted on gear tightly.
If bearing rotation is uneven, noising, or loose bearing mounted, then replace it.
Check oil seal for wear or damage, and replace it if necessary.




Check gear box cover bearing as the same way above, and replace it if necessary.

Caution

- If remove the drive shaft from the cover upper side, then its bearing has to be replaced.

Check drive shaft and gear for wear or damage.



Bearing Replacement


Caution

- Never install used bearings. Once bearing removed, it has to be replaced with new one.

Remove driving shaft bearing and counter shaft bearing from left crankcase using following tools:

Special tool:

Inner bearing puller



Install new drive shaft bearing and counter shaft bearing into left crankcase.

Special tool:


Bearing driver (6301)



Remove oil seal, and then remove final shaft bearing from left crankcase.

Special tool:

Inner bearing puller




11. FINAL DRIVING MECHANISM



Install new final shaft seal.

Special tool:


Oil seal driver (27*42*7)



Install new final shaft bearing.

Special tool:

Bearing driver (6203/6004UZ)



Press out the drive shaft from gear box cover.


Use shaft protector as operation.

Remove oil seal from gear box cover and discard the seal.

Use inner bearing puller to remove the final shaft bearing and counter shaft bearing from the cover.

Special tool:

Inner bearing puller




If the drive shaft is pulled out with its bearing, then remove the bearing with bearing puller and shaft protector.

Special tool:

Multi-functional bearing puller or Outer bearing puller


Shaft protector



Install a new drive shaft bearing onto gear box cover.

Special tool:

Bearing driver (6204)




Install a new final shaft bearing and counter shaft bearing onto gear box cover.

Special tool:

Bearing driver (6203/6004UZ)

Bearing driver (6301)



Install drive shaft.



Special tool:

Drive shaft puller

Drive shaft install bush

Extension bush (long)

Extension bush (short)



11. FINAL DRIVING MECHANISM




Re-assembly of Final Driving Mechanism


Apply with grease onto the oil seal lip of final driving shaft.




Install countershaft, counter gear, final shaft and final driving gear.



Install dowel pin and new gasket.




Install gear box cover and bolts, and tighten.
Torque value: 1.0~1.4kgf-m



Apply with grease onto new oil seal lip, and then install the oil seal.

Special tool:

Oil seal driver (20*32*6)




Install driven pulley/clutch outer/belt.
Install movable drive face, drive face and left crankcase.
Install rear wheel.
Add gear oil.



Notes:

Mechanism Diagram	12-1	Starting Clutch	12-4
Precautions in Operation.....	12-2	A.C.G. Set Installation.....	12-6
Right Crankcase Cover Removal	12-3	Flywheel Installation.....	12-7
Flywheel Removal	12-4	Right Crankcase Cover Installation..	12-7
A.C.G. Set Removal.....	12-3		

Mechanism Diagram



Precautions in Operation

General information

- Refer to chapter 5: Engine removal and installation
- Refer to chapter 16: The troubleshooting and inspection of alternator
- Refer to chapter 16: The service procedures and precaution items of starter motor

Specification

Item	Standard value (mm)	Limit (mm)
ID of starting clutch gear	31.804~31.807	31.810
OD of starting clutch gear	42.505~42.510	42.507

Torque value

Flywheel nut	5.0~6.0kgf-m
Starting clutch hexagon bolt	1.0~1.4kgf-m with adhesive
8 mm bolts	0.8~1.2kgf-m
12 mm bolts	1.0~1.4kgf-m

Tools

Special tools

A.C.G. flywheel puller: SYM-3110A00

Universal holder: SYM-2210100

Right Crankcase Cover Removal

Remove bolts and screws from the right crankcase cover.



Remove cooling fan comp. (4 bolts 6×18) and then remove it.



Flywheel Removal

Hold the flywheel by drive face with universal holder, and remove its nut.

Special tool:
Universal Holder



Pull out flywheel with A.C.G. flywheel puller.

Special tool:
A.C.G. Flywheel puller




12. ALTERNATOR/STARTING CLUTCH




A.C.G. Set Removal

Remove 2 mounted bolts from pulse generator and 2 mounted bolts from wire clumper and then remove it.
Remove 2 screws from right crankcase cover and A.C.G. set.



Starting Clutch Removal


Use special tool for remove starting clutch gear comp. as show in this figure.



Remove starting driven gear.




Remove mounting plate, starter reduction gear, and the shaft.
Remove starting clutch gear comp.



Starting Clutch Inspection

Check the starting clutch gear for wear or damage.
Measure the ID and OD of the starting clutch gear.

Service Limit: ID: 31.810 mm
OD: 42.507 mm




Check the starting reduction gear and shaft for wear or damage.



Install one way clutch onto starting clutch gear.
Hold flywheel and rotate starting clutch gear.
The starting clutch gear should be rotated in C.C.W direction freely, but not C.W direction.
(View as show in this figure.)



Remove the rollers, spring caps, and springs of clutch on the one way clutch that located on the back of flywheel.
Check each roller and plug for wear or damage.
Install rollers, plugs and springs.



12. ALTERNATOR/STARTING CLUTCH



Remove 3 hexagon bolts with air and hex socket wrenches.



Disassembly


Install the components in the reverse procedures of removal.



Caution

Tape a tightening tape onto the thread of hexagon bolt.


Torque value: 1.0~1.4kgf-m



Installation

Install dowel pin and new gasket.

Install reduction gear shaft and reduction gear.



Install starting clutch gear onto crankshaft.



A.C.G. Set Installation

Install the A.C.G. set onto right crankcase cover (2 screws).

Install pulse generator (2 screws).

Tie the wire harness securely onto the indent of crankcase.

Caution

Make sure that the wire harness is placed under pulse generator.



Flywheel Installation

Hold the flywheel with flywheel holder, and tighten its nut.

Torque value: 5.0~6.0kgf-m

Tool:

Flywheel holder




The picture of flywheel after installing



Right Crankcase Cover Installation


Install cooling fan comp. (4 bolts 6×18) onto flywheel. Install right crankcase cover.



Notes:

Mechanism Diagram	13-1	Disassembly of crankcase	13-3
General information	13-2	Crankshaft Inspection	13-5
Trouble diagnosis	13-2	Assembly of crankcase	13-6

Mechanism Diagram



General information

Operational precautions

- This Section concerns disassembly of the crankcase for repair purpose.
- Remove following components before disassembling crankcase.
 - Engine Section 7
 - Cylinder head Section 8
 - Cylinder and piston Section 9
 - Drive pulley and driven pulley Section 10
 - AC generator/Start driven gear Section 12
 - Starting motor Section 18
- In case it requires replacing the crankshaft bearing, the driving chain of engine oil pump or the timing chain, it is preferably to replace crankshaft as a unit.

Specification

Unit: mm

	Item	Standard	Limit
Crankshaft	Connecting rod side clearance of the big end	0.100~0.400	0.600
	Vertical clearance of the big end of the connecting rod	0~0.008	0.050
	Run-out	-	0.100

Torque value

Bolts for crankcase	0.8~1.2kgf-m
Bolts for cam chain adjuster	1.2~1.6kgf-m

Tools

Special tools

R/L. crank disassemble/ install tool: SYM-1300001-H9A
L. crank shaft bearing driver: SYM-9100200-H9A
Crank shaft bearing fixing socket: SYM-9100210-H9A
Crank shaft puller: SYM-1130000-H9A
L. crank shaft oil seal driver (25*40*8): SYM-9121600
Outer bearing puller: SYM-6204010
Inner bearing puller: SYM-6204020
Clutch nut wrench: SYM-9020200


Trouble diagnosis

Engine noise


- Loose crankshaft bearing
- Loose crankshaft pin bearing
- Worn out piston pin and pin hole

Disassembly of crankcase


Loosen the bolt and remove the tensioner.



Loosen 2 bolts on the right crankcase.



Loosen 4 bolts on the left crankcase.
Remove cam chain.



Place right crankshaft case downward and left up crankcase.

Caution

Care should be taken not to damage the contact surfaces.




13. CRANKCASE / CRANK




Remove crank by left crank shaft.
Refer to chapter 2: Special tools

Special tool:

R/L. crankcase disassemble/install tool
(SYM-1120000-H9A)




Remove crankshaft from right crankcase.




Remove gasket and dowel pins.
Scrape gasket residues off the crankcase contact surface.

⚠ Caution

Do not damage contact surface of the gasket.
It is better to moisten the gasket residue for
easy scrapping.




Check oil line lubricate the cylinder.
Check any damage in oil seal and scrape gasket.
Replace with new one if damaged.



Crankshaft Inspection


Use a thickness gauge to measure left and right clearance of connecting rod big end.

Service limit: 0.6 mm




Measure the clearance of the big end at the vertical directions.

Service limit: 0.05 mm



Place the crankshaft on a V-block, measure run-out of the crankshaft.

Service limit: 0.10 mm



Check crankshaft bearing

Use hand to crank the bearing to see it moves freely, smoothly and noiseless.


Check the inner ring to see it links firmly on the bearing.

If any roughness, noise and loose linkage are detected, replace the bearing with new one.

Caution

The bearing shall be replaced in pair.

Special tool: outer bearing puller



Assembly of crankcase

Special tool:

R/L. crankcase disassemble/install tool


L. crankshaft bearing driver

Crankshaft bearing fixing socket

Crankshaft puller

Clutch nut wrench

The new bearing and bearing driver, puts on the left crankcase.




Install R/L. crankcase disassemble/install tool on the left crankcase.


Again turns on crankshaft puller on the bearing driver spiral tooth.

Gradually tightens the crankshaft puller upper cap nut, presses in the bearing to locate.

After the bearing presses in to locate, opens the R/L. crankcase disassemble/install tool, takes down the bearing driver.



Installs crank to the left crankcase.




Direct the crankshaft bearing fixing socket to crankshaft.




Install R/L. crankcase disassemble/install tool on the left crankcase.
Again turns on crankshaft puller on the crankshaft spiral tooth.

⚠ Caution


Crank shaft puller lock into on as far as possible the crank spiral tooth, prevented pulls the bad crank spiral tooth.




Gradually tightens the crankshaft puller upper cap nut, drags into the crank to locate.



Install 2 new dowel pin and new gasket.
Install the right crankcase onto the left crankcase.




Tighten 2 bolts on the crankcase.
Torque value: 0.8~1.2kgf-m



13. CRANKCASE / CRANK



Tighten 4 bolts on the crankcase.
Torque value: 0.8~1.2kgf-m



Clean the crankshaft.
Apply a layer of grease on the lip of oil seal, Puts
on the left crank shaft.
Install the oil seal in the left crankcase with care
not to damage the lip of the oil seal.




By oil seal driver (25×40×8), oil seal will knock into
location.

Special tool:
Oil seal driver (25*40*8)



Install the tensioner and tighten the bolts.
Torque value: 1.2 ~1.6kgf-m
Install the cam chain.




Notes:

Mechanism Diagram	14-1	Rear carrier.....	14-9
Maintenance.....	14-2	Body cover	14-10
Front cover.....	14-3	Inner box.....	14-11
Handle front cover.....	14-4	Floor panel	14-6
Handle rear cover	14-5	Front fender.....	14-13
Side cover	14-6	Rear fender.....	14-15
Front under spoiler	14-7	Center fender	14-15
Luggage box	14-8		


Mechanism Diagram

14



Maintenance

Body covers disassemble sequence:



- Be careful not to damage various covers in assembly or disassembly operation.
- Never injure hooks molded on the body covers.
- Align the buckles on the guards with slot on the covers.
- Make sure that each hook is properly installed during the assembly.
- Never compact forcefully or hammer the guard and the covers during assembly.

Front cover

Remove


Loosen 8 screws from the front cover.



Loosen 2 screws bottom of front handle cover.




Remove headlight coupler, and then remove front cover.



Installation

Install in reverse order of removal procedures.



14. BODY COVER



Handle front cover

Disassembly


Loosen 4 screws from handle rear cover rear side.



Loosen 1 screw from front handle cover.



Remove front winker light cord coupler.



Remove the handle front cover.




Handle rear cover

Remover


Remove front cover.

Remove speedometer cable.


Disconnect each switch connectors.



Remove electric line from the electric systems.



Loosen 2 screws from the handle rear cover.



Loosen 1 screw from backside of the handle rear cover.

Remove handle rear cover.




14. BODY COVER



Floor panel

Remove

Loosen 4 bolts from the right & left step bar.
Remove the right & left step bar covers.



Side cover

Remove

Loosen 3 screws from the left side cover.
Loosen 3 screws from the right side cover.



Remove the right & left side cover.



Installation

Install in reverse order of removal procedures.

Front under spoiler

Remove

Remove front cover.

Loosen 4 screws of the inner box side.



Loosen 2 screws from front side of the front under spoiler.



Remove the front under spoiler.



Installation

Install in reverse order of removal procedures.

14. BODY COVER



Luggage box


Remove

Open seat.

Loosen 4 nuts of the luggage box.



Loosen 1 screw & 2 bolts from inside of the luggage box.



Remove the luggage box.



Installation

Install in reverse order of removal procedures.

Rear carrier**Remove**

Loosen 4 bolts from the rear carrier.



Remove the rear carrier.

**Installation**

Install in reverse order of removal procedures.

14. BODY COVER




Body cover

Remove


Remove luggage box and rear carrier.
Remove DC sole cable seat and lock comp.



Loosen 2 bolts from the taillight underneath.
Loosen 1 bolt 6mm and 2 washer bolts 6x12.



Loosen 2 screws from the center cover.
Loosen 2 screws from the left and right body covers.



Remove electric line coupler from the taillight.
Remove right and left body covers.



Installation

Install in reverse order of removal procedures.


Inner box

Remove

Remove the front cover.

Loosen 1 bolt from the setting at hook and remove the hook.

Remove main switch cover.



Loosen 2 screws 5x16 from the under spoiler.



Remove the inner box.




Installation

Install in reverse order of removal procedures.


14. BODY COVER



Remove the battery.



Remove CDI and Relay from front cover.



Loosen 4 bolts from the floor panel.




Installation

Install in reverse order of removal procedures.

Front fender

Remove


Remove Fr.Inner fender A & Fr.Inner fender B. (4 screws and 2 bolts)



Upward pushes, after causes the tenon to fall off front, again takes out the front inner fender B.

Caution

- When disassemble age must pay attention, whether the tenon is separated from.
- Cannot hardly pull out, is easy to create the tenon to break off.



Remove speedometer cable. (1 screw)




From front fender left side remove brake pipe clip.



14. BODY COVER



Use drive plus minus, remove front fender (4 screws).



Downward presses the front fender, will cause it to be separated from the front cushion, and then take down to front.



Installation

Install in reverse order of removal procedures.

Rear fender

- Remove luggage box and seat.
- Remove rear carrier.
- Remove body cover.
- Remove rear fender upper side bolts. (2 bolts)
- Remove rear inner fender.



Remove rear fender as show in this picture.




Installation


Install in reverse order of removal procedures.

Center fender

- Remove air cleaner.
- Remove center fender left side bolt. (1 bolt)



Remove center fender right side bolts, and then remove center fender. (2 bolts)




Installation

Install in reverse order of removal procedures.


Notes:

Mechanism Diagram-Front Disk Brake 15-1	Brake fluid replacement / Air-bleed 15-7
Mechanism Diagram-Rear Drum Brake 15-2	Disk Brake-Caliper 15-8
Maintenance Description 15-3	Brake Disk 15-9
Trouble Diagnosis 15-4	Disk Brake - Master Cylinder 15-9
Disk Brake System Inspection 15-5	Rear Drum Brake 15-12
Adding Brake Fluid 15-6	

Mechanism Diagram-Front Disk Brake



Mechanism Diagram-Rear Drum Brake



Maintenance Description

Operational precautions

Caution

Inhaling asbestos may cause disorders of respiration system or cancer, therefore, never use air hose or dry brush to clean brake parts. Use vacuum cleaner or other authorized tool instead.

- The brake caliper can be removed without removing the hydraulic system.
- After the hydraulic system is removed, or the brake system is felt to be too soft, bleed the hydraulic system.
- While refilling brake fluid, care should be taken not to let the foreign material entering into the brake system.
- Do not spill brake fluid on the painted surfaces, plastic or rubber parts to avoid damage.
- Check the operation of the brake system before riding.

Specifications

Item	Standard (mm)	Limit (mm)
The thickness of front and rear brake disk	4.000	2.500
Front and rear brake disk eccentricity	< 0.100	0.300
Master cylinder inner diameter	11.000 - 11.043	11.055
Master cylinder outer diameter	10.957 - 10.984	10.945
Diameter of front disk	273.000	-
Diameter of rear brake drum	130.000	-
Thickness of front brake lining	5.100	2.000
Thickness of rear brake lining	5.100	2.000

Torque values

Front brake hose bolts	3.0~4.0kgf-m
Bolt for front brake caliper	3.0~3.5kgf-m
Bolts for the front brake disk	4.0~4.5kgf-m
Brake lever nut	0.8~1.2kgf-m
Nut for the rear brake arm	0.5~0.6kgf-m
Air-bleed valve	0.5~0.6kgf-m

Trouble Diagnosis

Disk Brake

Soft brake lever

1. Air inside the hydraulic system
2. Hydraulic system leaking
3. Worn master piston
4. Worn brake pad
5. Poor brake caliper
6. Worn brake lining/disk
7. Low brake fluid
8. Blocked brake hose
9. Warp/bent brake disk
10. Bent brake lever

Hard operation of brake lever

1. Blocked brake system
2. Poor brake caliper
3. Blocked brake pipe
4. Seized/worn master cylinder piston
5. Bent brake lever

Drum Brake

Poor brake performance

1. Improper brake adjustment
2. Worn brake lining
3. Worn brake drum
4. Worn brake cam
5. Improper brake lining installation
6. Seized brake cable
7. Dirty brake lining
8. Dirty brake drum
9. Brake pad worn in brake cam area.
10. Poor contact between brake arm and camshaft indent

Uneven brake

1. Dirty brake lining/disk
2. Poor wheel alignment
3. Clogged brake hose
4. Deformed or warped brake disk
5. Restricted brake hose and fittings

Tight brake

1. Dirty brake lining/disk
2. Poor wheel alignment
3. Deformed or warped brake disk

Brake noise

1. Dirty lining
2. Deformed brake disk
3. Poor brake caliper installation
4. Imbalance brake disk or wheel

Tight operation or low return speed of brake lever

1. Worn/broken/crack return spring
2. Worn drum
3. Dirty brake lining
4. Brake seized caused from dirty brake drum
5. Seized brake cable
6. Worn brake cam
7. Improper brake lining installation


Brake noise

1. Worn brake lining
2. Worn drum
3. Dirty brake lining
4. Dirty brake drum


Disk Brake System Inspection

Inspection

By visual examination whether divulges or the damage, with spanner inspection brake tube seam whether becomes less crowded, and the inspection handle bar turn right or turn left, or pressure the cushion, whether besides the pipeline protection department, whether there is interferes, contacts other parts of.




Check the brake from behind the brake caliper. The brake pad must be replaced with new lining when the brake pad wear limit reaches the brake disk.



Park the motorcycle on a level ground, and check if fluid level is under the “LOWER” mark. Recommended Brake Fluid: WELL RUN BRAKE OIL (DOT 3).

Caution

- The vehicles inclined or just stop, the survey oil level could not be accurate, had to settle the 3~5 minute.
- In order to prevent has the chemical change, please do not use counterfeiting or other unclear trade marks brake fluid.
- Uses by all means must with the trade mark brake fluid, guarantees the ghost vehicle efficiency.



Adding Brake Fluid

Before the brake fluid reservoir is removed, turn the handle so that the brake fluid reservoir becomes horizontal, and then remove the brake fluid reservoir.

When maintenance brake system, will be supposed to paint the surface or the rubber parts catches up by the rags.

Caution



Supplement brake fluid please do not surpass the upper limit, spilled brake fluid on painted surfaces, plastic or rubber components may result in their damages.

Remove the master cylinder cap and diaphragm. Increases the high quality brake fluid, uses by all means must with the trade mark brake fluid joins in the master cylinder.

Clean the dirty brake disk.

Caution

- The dirty brake lining or disk will reduce the brake performance.
- To mixed non-compatible brake fluid will reduce brake performance.
- Foreign materials will block the system causing brake performance to be reduced or totally lost.



Brake fluid replacement / Air-bleed

Connect drain hose to air-bleed valve.

Open the drain valve on the caliper and operate the brake lever until the old brake fluid is entirely drained out.

Close the drain valve and add specified brake fluid into the brake master cylinder.

Recommended brake fluid: WELLRUN DOT 3 brake fluid

Connect one end of transparent hose to the drain valve, and put the other end into a container. Open the drain valve around 1/4 turns, and at the same time hold the brake lever until there is no air bubble in the drain hose and also feeling resistance on the brake lever.

Close the drain valve when finishing the brake system refilling fluid procedure, and operate the brake lever to check whether air bubble is in brake system or not.

If brake is still soft, please bleed the system as described below:



1. Tightly hold the brake lever and open the drain valve around 1/4 turns, and then close the valve.



Caution

- Do not release the brake lever before the drain valve is closed.
- Always check the brake fluid level when carrying out the air bleeding procedure to avoid air into the system.

2. Slowly release the brake lever, and wait for a few seconds until it reaches its top position.
3. Repeat the steps 1 and 2 until there is no air bubble at the end of the hose.
4. Tightly close the drain valve.
5. Make sure the brake fluid is in the UPPER level of the master cylinder, and refill the fluid if necessary.
6. Cover the cap.




Disk Brake - Caliper

Removal


Place a container under the brake caliper, and loosen the brake hose bolt and finally remove the brake hose.

⚠ Caution

Do not spill the brake fluid on painted surfaces.



Remove two caliper bolts and the caliper.




Disassembly

Make sure the brake lining condition. Replace the lining if the brake lining wear limitation groove close to the brake disk.

Brake lining replacement

Compress the caliper and let the brake lining out of the caliper mounting plate. Compress the brake lining locking spring. Remove the inner brake lining firstly and then remove the outer brake lining. Compress the brake caliper at first as installation. Install the inner brake lining firstly, and then install the outer brake lining.



Installation

Install the brake caliper and tighten the attaching bolts securely.

Torque: 3.3kgf-m


⚠ Caution

- Use M8 x 35 mm flange bolt only.
- Long bolt will impair the operation of brake disk.

Use two seal washers and hose bolts to lock the hose and brake caliper in place.

Torque: 3.5kgf-m

Refill up the brake fluid to the reservoir and make necessary air bleeding.




Brake Disk

Inspection

Visually check the brake disk for wear or break. Measure the thickness of the disk at several places. Replace the disk if it has exceeded the service limit.

Allowable limit: 2.0 mm




Remove the brake disk from wheel. Check the disk for deformation and bend.

Allowable limit: 0.30 mm

⚠ Caution

- The dirty brake lining or disk will reduce the brake performance.
- Brake lining includes the asbestos ingredient, cannot use the air-gun to be clean, the operator should dress the mouthpiece and the glove, use vacuum cleaner clean it.



Disk Brake - Master Cylinder


Master Cylinder Removal

⚠ Caution


Do not let foreign materials enter into the cylinder.

⚠ Caution

The whole set of master cylinder, piston, spring, diaphragm and cir clip should be replaced as a set.




Remove the front and rear handlebar guards.
Remove the leads of brake lamp switch.
Drain out the brake fluid.
Remove the brake lever from the brake master cylinder.
Remove the brake hose.
Remove the master cylinder bolts and the master cylinder.
Remove the rubber pad.
Remove the cir clip.
Remove the piston and the spring.
Clean the master cylinder with recommended brake fluid.



Master Cylinder Inspection


Check the master cylinder for damage or scratch.
Replace it if necessary.
Measure the cylinder inner diameter at several points along both X and Y directions.
Replace the cylinder if the measured values exceed allowable limit.

Allowable limit: 12.550 mm



Measure the outer diameter of the piston.
Replace the piston if its measured value exceeds allowable limit.

Allowable limit: 12.654 mm



Master Cylinder Assembly

⚠ Caution

- It is necessary to replace the whole set comprising piston, spring, piston cup, and cir clip.
- Make sure there is no dust on all components before assembling.


Apply clean brake fluid to the piston cup, and then install the cup onto the piston.
Install the larger end of the spring onto the master cylinder.

The master cup's cavity should be face inside of master cylinder when installing the master cup.
Install the cir clip.

⚠ Caution


- Never install cup lip in the opposite direction.
- Make sure the cir clip is seated securely in the groove.

Install the rubber pad into groove properly.



Master Cylinder Install


Install the rubber pad into the groove correctly.
Place the master cylinder onto handlebar, and install the bolts.
Install the brake lever, and connect leads to brake light switch.



Connect brake hoses with 2 new washers.
Tighten the brake hose bolt to the specified torque value.
Make sure the hose is installed correctly.
Install all wires, hoses, and components carefully so avoid to twisting them together.

Caution

Improper routing may damage leads, hoses or pipes.



Caution

Kink of brake leads, hose or pipe may reduce brake performance.

Add specified brake fluid and bleed the system.


Rear Drum Brake

Remove brake drum

Remove wheel and brake drum.
To use vacuum cleaner or other alternatives to avoid danger caused from dusts.

⚠ Caution

- Inhaling brake lining ashes may cause disorders of respiration system, therefore, never use compressed air or dry brush to clean brake parts.
- Brake performance will be reduced by grease on brake lining.




Inspection brake drum

Check brake drum for damage or wear out, and replace it if necessary.
Measure the inner diameter of brake drum and record the max value.

Allowable limit: 131.0mm

⚠ Caution

- Clean the rust onto the brake drum with #120 sand-paper
- Measure the inner diameter of brake drum with micrometer



Brake lining inspection

Measure the thickness of brake lining at three points (both ends and center).
If the thickness is less than specified value or if it is contaminated by oil or grease, replace as a set.


Service limit: Rear: 2.0 mm

Remove brake lining

To both hands pulls open brake lining, remove brake lining from brake.

⚠ Caution

Brake linings must be replaced as shoes.



Install brake lining

Apply with a thin coat of grease to the brake cam and the anchor pin.


Install brake cam.

Never allow brake linings to be contaminated by oil or grease.

Wipe off the excessive grease from brake cam and the anchor pin.

Caution


Brake efficiency will be reduced if brake lining is contaminated by oil or grease.



Rear brake panel

Apply a thin coat of grease between the oil seals on the brake cam shaft.


Install the brake cam and arm after aligning it with the punched point.



Tighten the bolts and nuts to specified torque:

Torque value: 0.5~0.6kgf-m


Hook on the return spring.



Notes:

Mechanism Diagram	16-1	Front Wheel	16-5
Operational Precautions	16-2	Front Cushion	16-8
Trouble Diagnosis	16-2	Steering Stem	16-9
Steering Handle	16-3		

Mechanism Diagram



Operational Precautions

General

Please refer to the Maintenance Manual of tubeless tire in respect to the removal, repair and installation of the tire.

Torque Values

Nut for the front wheel axle	5.0 ~ 7.0kgf-m
Nut for the steering handle	4.0 ~ 5.0kgf-m
Lock nut for the steering handle stem	1.0 ~ 2.0kgf-m
Top crown for the steering handle stem	0.2 ~ 0.3kgf-m
Locating screw for the speedometer cable	0.15 ~ 0.3kgf-m
Front cushion upper lock bolt	2.4 ~ 3.0kgf-m

Special Tools

Steering handle top thread wrench	SYM-5320000
Inner bearing puller	SYM-6204020
Steering nut wrench	SYM-6204010
Driver 32*35mm	
Driver 42*47mm	

Trouble Diagnosis

Hard to steer

- The steering handle stem nut is too tight.
- The ball and the top crown of the steering handle stem are damaged.
- Insufficient tire pressure.

The steering handlebar is tilted

- Uneven arrangement of the front cushion.
- The front fork is bent.
- The front wheel axle is bent.

The front wheel rim run-out

- The rim is bent.
- The wheel axle nut is not tightened enough.
- Side-worn or poor tire.
- The bearing clearance of the wheel axle is too large.

Soft front cushion

- The front cushion spring is worn out.
- The oil seal of the front cushion is leaking.

Noise in front cushion

- Front cushion is warped.
- The joint of the front cushion gets loose.


Steering Handle

Removal

Remove the handle front cover, handle rear cover and front cover. (Refer to chapter 13)
Loosen the lock bolts for the master cylinder of the front brake.

Caution


Do not let foreign materials enter into the cylinder.



Remove throttle holder, cap, cable and grip after mounting screw removed.



Remove rear brake lever mounting nut and bolt, and then remove brake lever and cable.
Remove rear brake lever bracket after mounting bolt removed.



Loosen handle mounting nut.
Remove handle mounting bolt, and then remove the handle.



Installation

Install handle and align with bolt hole.
Install bolt and nut and then tighten it.

Torque value: 4.5kgf-m




Apply with grease onto throttle cable and the sliding surface of handle.
Align the lock pin of the throttle bracket with the hole on the handle, and then install the throttle bracket.


⚠ Caution

When installs the throttle cable, first spreads the grease in the terminal to receive the throttle grip again.

- After installs the handle, inspects the throttle grip, whether may change to in the direction the handle time the free position, the freedom does moves.




Install the lock bolts for the master cylinder of the front brake.



Align the lock pin with the hole on the handle and also install brake lever bracket. Then, tighten the brake lever bracket bolt.
Install brake cable, lever on to bracket, and then tighten lever screw and nut.

After the installment completes, carries on the following inspection and the adjustment:

- Throttle grip operation.
- All electric appliances, the meter function.



Front Wheel

Remove

First by the bracket strut frame base, causes the front wheel to float off.
Remove the speedometer cable.
Turn loose the axle nut.



Pull out the front wheel axle.
Remove the front wheel.

⚠ Caution

Care shall be taken not to push the brake lever to avoid the brake pad being squeezed out. In case that the brake pad is accidentally squeezed out, use a screwdriver to force it back to the place.




Inspection

Wheel axle

Place the wheel axle on a V block, measure its run out.

Service limit: 0.2 mm




Bearing

Use finger to move the inner ring of each bearing, it shall move smoothly and quietly. Check the outer ring is securely attached on the wheel hub. If the motion of the inner ring of the bearing is not smooth, or noisy and loose when being moved, remove and discard it.

⚠ Caution

The bearing shall be replaced in pair.



Wheel


Place the wheel on to a rotation seat to check its rim wobbling.

Turn the wheel with hand and measure its rim wobbling value with a dial gauge.

Service limit:

Radial: 2.0 mm (0.08 in)

Axial: 2.0 mm (0.08 in)



Disassembly


Remove 5 bolts and brake disk.

Remove dust seal, bearing and dist collar from left side.

Remove dust seal, bearing and retainer hear box from right side.

Special tools:

Inner bearing puller (SYM-6204020)



Assembly

Fill out the block of bearing by grease.

Drive the left bearing, dust seal and install the dist. collar.


Install the right side bearing.

⚠ Caution

- Carefully install the bearing in correct and evenly.
- Bearing outer face should be faced up as bearing installation.

Install the brake disk and then tighten the bolts

Torque value: 4.5kgf-m



Install right side dust seal.


Lubricate the retainer with grease and install into the wheel hub.

Align the flange part on the speedometer gear with the slot of wheel hub.

⚠ Caution

Contaminated brake lining will reduce brake performance so the brake lining, brake drum and disc must be free of grease.

Apply with grease onto the left side dust seal.
Install the dust seal and side collar.



Installation

Open out brake lining with brake caliper.
Place the front wheel between the front cushion.

Caution


Align the gear box groove with the stopper flange.

Insert the wheel axle into the wheel and the install the wheel axle nut.

Tighten the nut.

Torque value: 5.0~7.0kgf-m

Connect the speedometer cable to the speedometer gear box.



Front Cushion

Remove


Remove front cover, front under spoiler and front fender.

Remove front brake caliper.

Remove front wheel.



Remove front cushion upper mounting bolts, and then remove front cushion.




Installation

Align the cover flange with upper level of the cushion clamp, and then tighten bolts.

Torque value: 2.7kgf-m

Install the removed components in reverse order of removal procedures.



Steering Stem

Remove

Remove handle, front wheel and front cushion.
Remove the steering stem mounting nut.
Remove top cone race and front fork.



⚠ Caution

Place the steel ball onto a parts container to prevent from missing.

Slightly tap the top and bottom ball bearing seats with a plastic hammer to remove the seats.
Remove bottom cone race body with a punch.

⚠ Caution

Do not damage the steering stem.




Installation

Install a new bottom cone race onto the steering stem.
Push the cone race until to mounted position.

⚠ Caution

Do not tilt the ball bearing seats as installation.

Apply with grease onto the ball bearing seats, and install steel balls onto the seats.
(Top: 26 balls, bottom: 29 balls)




Lubricate the top cone race seat with grease.
Screw the cone race in to top ball bearing seat till touching, and then screw out the cane race 1/4~3/8 turns.

Torque value: 0.25kgf-m

⚠ Caution


Check the steering stem that should be rotated freely and no clearance in vertical direction.




Install the steering stem mounting nut and tighten the nut by means of holding the top cone race body.

Torque value: 1.0~2.0kgf-m

Install in reverse order of removal procedures.




Shake steering handle up & down, left & right, and front & rear to check if it is loosen, has too much resistance and pulls to one side. Check steering handle if it is being pulled too tight by the brake cables.



Notes:

Mechanism Diagram	17-1	Muffler	17-3
Operational Precaution	17-2	Rear Wheel	17-3
Trouble Diagnosis	17-2	Rear Cushion	17-5

Mechanism Diagram



Operational Precaution

General

Please refer to the Maintenance Manual for tubeless tire in respect to the removal, repair and installation of the tires.

Service data

Unit: mm

Item		Standard	Allowable Limit
Run-out of rear rim	Radial	-	2.0
	Axial	-	2.0
Thickness of rear brake lining		5.1	2.0
Sustaining stroke of rear cushion		72	-

Torque Value

Rear wheel shaft nut	10.0~12.0kgf-m
Rear cushion upper bolt	3.5~4.5kgf-m
Rear cushion under bolt	2.4~3.0kgf-m
Rear fork mounting bolt	4.0~5.0kgf-m
Exhaust muffler mounting nut	1.0~1.2kgf-m
Exhaust muffler mounting bolt	3.2~3.8kgf-m

Trouble Diagnosis

Run-out of rear wheel

- Deformed or bent wheel hub.
- Improper tires.
- Loose wheel shaft.

Soft Cushion

- The spring is too weak.

Noisy Brake

- Worn brake lining.
- Offset brake disc.
- Improper assembly of brake caliper.
- Brake disc or wheel imbalance.

Poor Performance of Brake

- Improperly adjusted brake.
- Contaminated brake disc.
- Worn brake lining.
- Air inside brake fluid pipe.
- Grease on brake disc.
- The brake fluid piping is clogged.
- The brake fluid pipe is deformed or bent.
- Insufficient amount of brake fluid in the reservoir.

Muffler

Removal

Loosen the 2 nuts from exhaust muffler front side.



Loosen the 3 mounting bolts by exhaust muffler right side.

Remove the exhaust muffler.

Installation

Install in reverse order of removal procedures.

⚠ Caution

Replace the front side muffler pipe gasket if worn or deformed.

Torque Value

For mounting bolt: 3.2 ~ 3.8kgf-m

For mounting nut: 1.0 ~ 1.2kgf-m



Rear Wheel

Removal

Remove the exhaust muffler.

Remove the lower bolt of the right side rear cushion.

Remove 2 bolts of the rear fork.

Remove 1 nut of the rear wheel shaft, and then remove outside collar.



Remove the rear fork, fork inside collar, and then remove the rear wheel.




Inspection

Rear wheel rim


Place the wheel rim on a rotational support.
Rotate it by hand and measure the run-out with a dial indicator.

Run-out limit: 2.0 mm



Rear fork bearing

Rotate the inner ring of the bearing with a finger.
The bearing should move smoothly and quietly.
Check the fit of the bearing and rim.
Replace the bearing if its motion is not smooth or noisy.




Replacement of rear fork bearing


Remove the outside dust seal of the rear fork.
Use inner cir clip plier to remove the bearing lock clip.
Pull off the rear fork bearing by means of the inner bearing puller.
Remove the inside dust seal.

⚠ Caution

Never reuse the old dust seal on the bearing.



Press in the bearing into the rear fork by bearing driver.
Install the oil bearing lock clip.
Install new dust seals into rear fork two sides.



Installation

Install the rear wheel.
Install the inside collar on the rear fork.
Install the rear fork onto the rear wheel shaft.
Mount the outside collar on the rear fork.
Tighten the rear wheel shaft nut.

Install the rear fork mounting bolts and tighten the bolts.

Align the rear cushion with the rear fork hole;
tighten the cushion with bolts.

Install the exhaust muffler, first tighten front side mounting nuts, and then tighten the mounting bolts.

Torque Value

Rear wheel shaft nut: 10.0~12.0kgf-m

Rear cushion under bolt: 2.4~3.0kgf-m

Rear fork mounting bolt: 4.0~5.0kgf-m

Exhaust muffler mounting nut: 1.0~1.2kgf-m

Exhaust muffler mounting bolt: 3.2~3.8kgf-m

⚠ Caution

Attention must be paid to their direction when rear fork collars are installed. The small ends of inner and outer collars must face to rear fork bearing.



Rear Cushion

Removal


Remove the luggage box, rear carrier and body covers.

Loosen the mounting bolts of the air cleaner (2 bolts).

Remove the exhaust muffler (3 bolts, 2 nuts).

Remove the under bolts by left / right rear cushions.

Remove the upper bolts by left / right rear cushions, and then remove the cushion.



Installation

Install in reverse order of removal procedures.

⚠ Caution

The rear cushion must be replaced as a unit. Never disassemble the rear cushion as that would damage the structure.

Torque Value

Rear cushion upper bolt: 3.5~4.5kgf-m


Rear cushion under bolt: 2.4~3.0kgf-m



Notes:

Mechanism Diagram	18-1	Meters	18-11
Maintenance Data	18-2	Light / Bulb	18-12
Technical Specification	18-2	Switch / Horn	18-14
Trouble Diagnosis	18-3	Fuel Unit	18-17
Battery	18-4		
Charging System	18-5		
Ignition System	18-8		
Starting System	18-10		

Mechanism Diagram



18

Maintenance Data

Operational precaution

- When remove the battery, the disconnection sequence of cable terminals shall be strictly observed. (First disconnect the negative cable terminal, next, the positive cable terminal.)
- The model of the spark plug and the tightening torque.
- The ignition timing.
- Adjustment of headlight.
- Removal and installation of AC generator.
- The maintenance free battery requires no inspection of electrolyte level and refilling of distilled water.
- To recharge the battery, remove the battery from rack without removing ventilation caps.
- Unless in emergency, never rapid charge the battery.
- The voltage must be checked with the voltmeter while charging the battery.
- As C.D.I assembly does not require an ignition timing check. In case ignition timing is incorrect, check C.D.I and AC generator. Verify with an ignition timing light after replacement if necessary.

Technical Specification

Charging system

Description		Specification
Battery	Capacity	12V8Ah
	Charging rate	0.9A / 5 hours (standard) 4A / 1 hour (fast charging)
Leak current		< 1 mA
Charging current		1.2 A / 2000 rpm
Control voltage in charging		14.5 + 0.5 V / 2000 rpm

Ignition system

Description		Specification
Spark plug	Model	NGK CR8E (Recommended)
	Gap	0.6 - 0.7 mm
Ignition coil and resistance	Primary winding	$0.17 \pm 10\% \Omega$
	Secondary winding	Without cap: $3.1 \pm 10 K\Omega$
		With cap: $8.1 \pm 10 K\Omega$
Ignition timing "F" mark	13° TDC / 1000 rpm	
	27° TDC / 6000 rpm	

Trouble Diagnosis

No voltage

- Battery discharged
- The cable disconnected
- The fuse is blown
- Improper operation of the main switch

Low voltage

- The battery is not fully charged
- Poor contact
- Poor charging system
- Poor voltage regulator

No spark produced by spark plug

- The spark plug is out of work
- The cable is poorly connected, open or short-circuited
 - Between AC.G. and C.D.I.
- Poor connection between C.D.I. and ignition coil
 - Poor connection between C.D.I. and the main switch
- Poor main switch
- Poor C.D.I.
- AC.G. is out of work

Starter motor does not work

- The fuse is blown
- The battery is not fully charge
- Poor main switch
- Poor starter switch
- The front and rear brake switches do not operate correctly
- Starter relay is out of work
- The ignition coil is poorly connected, open or short-circuited
- The starter motor is out of work

Intermittent power supply

- The connector of the charging system becomes loose
- Poor connection of the battery cable
- Poor connection or short-circuit of the discharging system
- Poor connection or short-circuit of the power generation system

Charging system does not operate properly

- Burnt fuse
- Poor contact, open or short circuit
- Poor regulator
- Poor ACG

Engine does not crank smoothly

- Primary winding circuit
 - Poor ignition coil
 - Poor connection of cable and connectors
 - Poor main switch
- Secondary winding circuit
 - Poor ignition coil
 - Poor spark plug
 - Poor ignition coil cable
 - Current leakage in the spark plug
- Incorrect ignition timing
 - Poor AC.G.
 - Improper installation of the pulse sensor
 - Poor C.D.I.

Weak starter motor

- Poor charging system
- The battery is not fully charged
- Poor connection in the windings
- The motor gear is jammed by foreign material


Starter motor is working, but engine does not crank

- Poor starter motor pinion
- The starter motor run in reverse direction
- Poor battery

Battery

Removal

Loosen 2 bolts and remove the battery cover.
Disconnect the negative cable terminal first, then the positive cable terminal.
Remove the battery from the motorcycle.



Voltage Check

Use the digital voltmeter to check the voltage of the battery.

Voltage:

Fully charged: 13.0~13.2 V at 20°

Undercharged: Below 12.3 V at 20°

Charging

Connect the positive terminal (+) of the charger to the battery positive terminal (+).


Connect the negative terminal (-) of the charger to the battery negative terminal (-).

	Standard	Maximum
Charging current	0.9A	4.0A
Charging time	5H	1H



⚠ Warning


- Keep flames away while recharging.
- Charging is completely controlled by the ON/OFF switch on the charger, not by battery cables.



⚠ Caution


- Never rapid charge the battery unless in emergency.
- Verify the battery is recharged with current and duration prescribed above.
- Large current and fast time to charge will render damage to the battery.

When installing the battery, coat the cable terminal with grease.



Charging System

Charging circuit



Current Leakage Inspection

Turn the main switch to OFF position, and remove the negative cable terminal (-) from the battery. Connect an ammeter between the negative cable terminal and the battery negative terminal.


⚠ Caution

- In the current leakage test, set the current range at the largest scale, then gradually decrease to the lower scale as the test process goes to avoid possible damage to the ammeter and the fuse.
- Do not turn the main switch to ON position during test.


If the leaked current exceeds the specified value, it may indicate a short circuit.

Allowable current leakage: Less than 1mA

Disconnect each cable one by one and take measurement of the current of each cable to locate the short circuit.



Inspection on Charging Voltage



⚠ Caution

- Before conducting the inspection, be sure that the battery is fully charged. If undercharged, the current changes dramatically.
- Use a fully charged battery having a voltage larger than 13.0 V
- While starting the engine, the starter motor draws large amount of current from the battery.

After the engine is warmed up, replace original battery with a fully charged battery.

Connect a digital voltmeter to the battery terminals.

Connect an ammeter between both ends of the main fuse.

⚠ Caution

When the probe is reversibly connected, use a voltmeter having an indication that the current flows from the positive or the negative direction and the measurement should be at zero, ammeter at one direction only.

⚠ Caution

- Do not use short-circuit cable.
- It is possible to measure the current by connecting an ammeter between the battery positive terminal and the cable position terminal, however, while the starter motor is activated, the surge current the motor draws from the battery may damage the ammeter. Use the kick starter to start the engine.
- The main switch shall be turned to OFF position during the process of inspection. Never tamper with the ammeter and the cable while there is current flowing through. It may damage the ammeter.

Connect a tachometer.

Turn on the headlight to high beam and start the engine.

Accelerate the engine to the specified revolution per minute and measure the charging voltage.

Specified Charging Current:

1.2 A / 6000 rpm

Control Charging Voltage:

14.5 + 0.5 V / 2000 rpm

⚠ Caution

To replace the old battery, use a new battery with the same current and voltage.

The following problems are related to the charging system, follow the instructions provided in the checking list to correct it if any one of the problems takes place.

- (1) The charging voltage can not exceed the voltage between two battery terminals and the charging current is in the discharging direction.
- (2) The charging voltage and current are too much higher than the standard values.

The following problems are not related to the charging system; correct it if any by following steps indicate in the checking list.

- (1) The standard charging voltage and current can only reach when the revolution of the engine exceeds the specified rpm.
 - Bulbs used exceed their rate and consume too much power.
 - The replacement battery is aged and does not have enough capacity.
- (2) The charging voltage is normal, but the current is not.
 - The replacement battery is aged and does not have enough capacity.
 - Battery used do not have enough electricity or is over charged.
 - The fuse of the ammeter is blown.
 - The ammeter is improperly connected.
- (3) The charging current is normal, but the voltage is not.
 - The fuse of the voltmeter is blown.

Inspection on regulator rectifier

Remove the front cover.

Disconnect two 3 pin couplers of the regulator rectifier.



Inspection the rectifier coupler to the wire harness passes the condition.

Item	Check Points	Standard Value
Main switch connection	R – B	Battery voltage (ON)
Battery connection	R – G	Battery voltage
Charging coil	Y – Y	0.17 ~ 0.8Ω

If the readings measured are not normal, check parts in the circuit.


If the parts are normal, then trouble is in the wiring.

If there is nothing wrong with parts and wiring, replace the regulator rectifier.



Ignition System

Ignition circuit diagram



C.D.I unit

Disconnect connectors of the C.D.I unit.

Check the following connectors as indicated in the table at the harness side.

Item		Points to check	Result
Main switch		Black ~ Green	-
Pulse generator		Blue/yellow ~ Green	100~130Ω
Ignition coil	Primary circuit	Black/yellow ~ Green	0.17±10%Ω
	Secondary circuit	Black/yellow ~ with no cap	3.6±10%KΩ
		Black/yellow ~ with cap	7.3~11KΩ

Inspection on Ignition Coil

Remove the luggage box.

Disengage the connector of the ignition coil and the spark plug cap.

Measure the resistance between the terminals of the primary winding.


Standard resistance: $0.17\Omega \pm 10\%$

Remove the cap from the spark plug and measure the resistance between the spark plug and the primary winding.

Standard resistance:


With no cap: $3.6K\Omega \pm 10\%$

With cap: $7.3\sim 11 K\Omega$



Replacement

Loosen the lock bolt and replace the ignition coil if necessary.



Inspection on Exciting Coil


Caution

The test can be carried out without removing the exciting coil from the engine.

Remove the front cover.

Disconnect coupler of the exciting coil.


Measure the resistance between the black/yellow terminal and the earth.



Inspection of Pulse Generator


Disconnect the coupler of the pulse generator and measure the resistance between the terminals of blue/yellow and green.

Standard resistance: $100\sim 130\Omega$



Starting System

Starting circuit diagram



Inspection on starter relay

Open the main switch.

Press the brake.

Push down the starter switch.

If a sound of “Looh Looh” is heard, it indicates the relay function normally.



Remove the luggage box.

Disconnect the negative cable terminal of the battery.

Disconnect the cable positive terminal from the relay.

Disconnect the positive cable of the starter motor.


Disconnect the coupler of the relay.

Connect an ohmmeter to the large terminal end.

Connect the yellow/red cable to the battery positive terminal and the green/yellow cable to the battery negative terminal.

Check the continuity of the large terminal end.

If there is no continuity, replace the relay.



Removal of Starter motor


Remove the battery cover (5 screws).
 Disconnect the cable negative terminal (-), then the cable positive terminal (+).
 Remove the luggage box.
 Remove the air cleaner.



Loosen the lock bolts and remove the starter motor.

Installation of Starter motor


Install in reverse order of removal procedures.



Meters

Removal


Remove handle front cover.
 Remove the front cover, and then remove meter coupler and handle switch coupler.
 Remove speedometer cable.



Remove handle rear cover and speedometer.
 Loosen 3 screws, and then remove speedometer from handle rear cover.

Installation of Starter motor

Install in reverse order of removal procedures.



Light / Bulb

Replacing bulb for headlight

Remove the front cover.

Disconnect the terminal coupler and the rubber sleeve from the headlight.

Remove the bulb spring holder and the bulb.
Replace with new bulb if necessary.




Caution

- Never touch the bulb with finger, which will create a heat point.
- Clean the fingerprint left on the bulb with alcohol.

Install the bulb of the headlight in reverse order of removal.

Upon completion of replacement, turn on the main switch to ensure the headlight works well.

Adjust the beam and distance of the headlight if necessary.




Replacing the Front winker light Bulb

Loosen fixing screws and remove the handle front cover (screws x 3).



Replace with new front winker light bulb.



Replacing Bulb of taillight

Remove the taillight lens (2 screws).



Replace taillight or winker light bulb.



Switch / Horn

Main Switch

Inspection

Remove the front cover.

Disconnect the main switch coupler.

Check the continuity between two points as indicated below:

Position \ Pin	BAT1	BAT2	I	E
LOCK			○—○	○—○
OFF			○—○	○—○
ON	○—○			
Wire Color	Red	Black	-	Green



Replacement of main switch

Disconnect the coupler of the main switch and loosen the lock bolts (bolt x 2).

Remove the main switch.

Install the new main switch and tighten the lock bolts (bolt x 2).

Install the main switch coupler.



Handle switch

Remove the handle front cover and rear cover.

Disconnect the coupler of handle.

Check the continuity between two points as indicated in the table below.


Start Switch / Headlight Switch

Position \ Pin	ST	E
FREE		
⚡	○—○	○—○
Wire Color	Yellow / Red	Green



Headlight Switch

	TL	CI	RE	HL	CI
●					
⚡	○—○				
☀	○—○			○—○	
Wire Color	Brown	Black		Brown/White	Black




Dimmer and Passing switch

Position \ Pin	HI	LO	HL	PASS
		○ — ○		
	○ — ○			
PASS	○ — ○			
Wire color	L	W	BR/W	B




Winker switch

Position \ Pin	R	WR	L
	○ — ○		
N	FROM R	○ — ○	
	PUSH OFF		
	FROM L		○ — ○
		○ — ○	
Wire color	Light Blue	Gray	Orange



Horn switch


Position \ Pin	BAT	HO
FREE		
	○ — ○	
Wire Color	Green	Light Green



Brake Switch


While grasp the brake lever firmly, the terminals of white/green and green/yellow of the brake should have continuity.

Replace the switch if damaged.




Horn

Remove the front cover.




Apply 12 V power source to two terminals of the horn, the horn should sound.

Replace the horn if necessary.



Fuel Unit


Open the seat.
Remove the luggage box.
Remove the rear carrier.
Remove the body cover.
Disconnect the coupler of the fuel unit.



Remove the fuel unit (screws x 4).

Caution


- Great care shall be taken not to damage or bend the float arm of the gauge.



When the float arm shifts to the F position or the E position, the resistance measured shall be as follows:

Position	Resistance
E (Empty)	97.5~107.5 Ω
F (Full)	4~10 Ω

Connect the wiring to the fuel unit and the ohmmeter as shown.




Connect the fuel unit coupler to the wire harness.
Turn on the main switch.
Move the float arm to verify the proper position the fuel gauge needle indicates.

Arm Position	Needle Position
Up (Full)	F (Full)
Down (Empty)	E (Empty)

Caution


While conducting the test, turn on the direction indication lamp to make sure that the battery is in serviceable condition.



Notes:

VS150 ELECTRICAL DIAGRAM

19



NAME	ELEC. DISTRIBUTION
DWG No.	0030Z-VS2-0000

Notes: